



CE 1026

INSTALLATION, SERVICE AND MAINTENANCE INSTRUCTIONS



***Explosion-proof electric multi - turn actuators
UM 2-Ex***

TEST CERTIFICATE

EXPLOSION-PROOF ELECTRIC MULTI – TURN ACTUATOR UM 2 - Ex

Type number Power supply V Hz

Serial number Set switch-off torque..... Nm

Production year Operating speed..... min⁻¹

Wiring diagram Adjusted number of revolutions.....

Warranty period months Transmitter

Serial number of electric motor

Serial number of transmitter

Serial number of controller

Explosion-proof version: Ex II 2 G Ex db IIC T5 Gb + Ex II 2 G Ex db eb IIC T5 Gb + Ex II 2 G c
+ Ex II 2 D Ex tb IIIC T100°C Db

Final report No.: IECEx FTZU 11.0001X/ FTZÚ 09 ATEX 0184X, IECEx FTZU 11.0002X /FTZÚ 09 ATEX 0185X

Design and type tests are in accordance with the following standards:

IEC/EN 60 079-0: Explosive atmospheres - Part 0: **Equipment general requirements – General requirements**

IEC/EN 60 079-1: Explosive atmospheres - Part 1: **Equipment protection by flameproof enclosures “d”**

IEC/EN 60 079-7 – Explosive atmospheres Part 7: **Equipment protection by increased safety “e”**

IEC/EN 60079-31: Explosive atmospheres – Part 31: **Equipment dust ignition protection by enclosure „t“.**

Tests made in accordance with TP 74 1060 00

Tests made by

Date Signature and stamp

COMPLETENESS CERTIFICATE

Used valve

Assembled by: Firm

Name

Warranty period months

Date Signature and stamp

INSTALLATION CERTIFICATE

Location

Installed by: Firm

Name

Warranty period months

Date Signature and stamp

Please read these instructions carefully before mounting and operating the actuator!

Contents

| | |
|--|----|
| 1. General data | 2 |
| 1.1 Purpose and applications | 2 |
| 1.2 Safety instructions | 2 |
| 1.3 Product influence to environment..... | 2 |
| 1.4 Data specified on electric actuator | 3 |
| 1.5 Terminology..... | 4 |
| 1.6 Instructions for staff training | 5 |
| 1.7 Warning for safety use | 5 |
| 1.8 Warranty conditions..... | 5 |
| 1.9 Under-guarantee and after-guarantee service | 6 |
| 1.10 Operation conditions | 6 |
| 1.11 Packing, transport, storing and unpacking | 8 |
| 1.12 Assessment of the product and packaging and removal of contamination..... | 9 |
| 2. Description, function and specifications | 9 |
| 2.1 Description and function..... | 9 |
| 2.2 Basic specifications | 12 |
| 3. Installation and dismantling of actuator | 18 |
| 3.1 Installation | 18 |
| 3.2 Dismantling..... | 21 |
| 4. Adjustment..... | 22 |
| 4.1 Adjustment of the torque unit | 22 |
| 4.2 Signaling switches adjustment (S5,S6) (Fig. 8) | 25 |
| 4.3 Position indicator adjustment (Fig.8) | 25 |
| 4.4 Adjustment of resistant transmitter (Fig.9) | 26 |
| 4.5 Adjustment of the Electronic Position Transmitter (EPV) - the Resistive Transmitter (Potentiometer) with the Converter PTK 1 | 26 |
| 4.6 Adjustment of Capacitive Transmitter CPT1/A (Fig.12) | 28 |
| 4.7 Adjustment of the DCPT3M transmitter | 29 |
| 4.8 Electric local control (Fig.15) | 32 |
| 5. Service and Maintenance | 33 |
| 5.1 Service..... | 33 |
| 5.2 Maintenance - extent and periodicity | 33 |
| 5.3 Maintenance to assure inexplosiveness | 34 |
| 5.4 Troubleshooting..... | 35 |
| 6. Accessories and Spare Parts | 36 |
| 6.1 List of the Spare Parts..... | 36 |
| 7. Enclosures..... | 37 |
| 7.1 Wiring diagrams UM 2-Ex | 37 |
| 7.2 Operation Logic Diagram of switches and relays..... | 38 |
| 7.3 Dimensional drawings | 39 |
| 7.4 Guarantee service check report | 44 |
| 7.5 Post guarantee service check report..... | 45 |
| 7.6 Commercial representation | 46 |

The Installation, Service and Maintenance Instructions are drawn up according to requirements of EC Executive Nr. 89/392/EEC "Uniform requirements for machines and devices from the point of view of safety and health care", to save life and health of users and to avoid material damages and exposure environment to danger.

1. General data

1.1 Purpose and applications

Explosion-proof electric multi-turn actuators (hereinafter **EA**) types **UM 2-Ex** designed for direct installations onto controlled devices (regulating bodies -valves, etc.). EA of **UM 2-Ex** types are provided for remote control in both directions of their movement. They can be equipped with means of measuring and control of technological processes where an unified analogue direct current or voltage signal is an information bearer on their input and/or output. They can be used in heating, energy, gas, air-conditioning and other technological systems, which they are suitable for, regarding their features. They are assembled by means of flange and connecting component in accordance with ISO 5210.



1. **It is forbidden to use EA as a lifting mechanism!**
2. **Switching of actuator by a semiconductor switches have to be consulted with producer.**

1.2 Safety instructions

Product characteristics from risk point of view

EA are reserved technical devices with higher rate of danger (group A), with possibility of installation in areas specially danger regarding casualties caused by electric current. EA are according to directive LVD 2014/35/EU and standard EN/IEC 61010-1 within valid edition assigned for installation category II (overvoltage category).

In order to demonstrate the compliance with the requirements of the European Council directive on machinery 2006/42/EC, European Parliament and Council Directive 2014/34/EU on equipment and protective systems intended for use in potentially explosive environment (designated as Directive ATEX 100a), directive of the Council 2014/35/EU on LVD and Council Directive 2014/30/EU on EMC, the electric actuators are subject to certification by authorized certification facilities.

The product meets the essential safety requirements according to EN 60204-1 and is in compliance with EN 55011/A1 within valid edition.

1.3 Product influence to environment

Electromagnetic compatibility (EMC): the product complies with the requirements of the Directive 2014/30/EU of the European Parliament and of the Council on the approximation of the laws the Member States relating to the electromagnetic compatibility and with the requirements of standards as well EN/IEC 61000-3-3 and EN/IEC61000-3-2 within valid edition.

Vibrations caused by the product: product influence is negligible.

Noise produced by the product: The maximum allowable noise level (A) of the product measured in a place of operation is 75dB (A).

Electromagnetic compatibility (EMC): the product complies with the requirements of the Directive 2014/30/EU of the European Parliament and of the Council on the approximation of the laws the Member States relating to the electromagnetic compatibility and with the requirements of standards as well EN/IEC 61000-3-3 and EN/IEC61000-3-2 within valid edition.

Vibrations caused by the product: product influence is negligible.

Noise produced by the product: The maximum allowable noise level (A) of the product measured in a place of operation is 78dB (A).

Electric actuators **UMR X-Ex** are made in explosion-proof version  **II 2G** Ex db IIC T5 Gb + :

 **II 2G c** +  **II 2G** Ex db eb IIC T5 Gb +  **II 2D** Ex tb IIIC T100°C Db. pursuant to.

EN/IEC 60079-0: Explosive atmospheres – Part 0 : Equipment general requirements – General requirements

EN/IEC 60079-1: Explosive atmospheres – Part 1 : Equipment protection by flameproof enclosures "d"

EN/IEC 60079-7: Explosive atmospheres - Part 7: Equipment protection by increased safety "e".

EN/IEC 60079-31: Explosive atmospheres – Part 31: Equipment dust ignition protection by enclosure „t“, within valid edition.

Electric parts EA are proposed:

- as devices of the group **II** for others threatened areas (excluding mines)
- of the category **2** with demanding requirements for safety
- for use in zone **1,2,21,22**
- for atmospheres **G** (gases, vapors or mists) or **D** (combustible conductive dusts)
- to pressure range from 0.8 to 1.1 bar.

Design version is :

- flameproof enclosures "**db**", increased safety "**eb**" or level dust ignition protection by enclosure "**tb**"
- with explosion protection group **IIC** or **IIIC**
- and temperature class **T5** (max. permissible surface temperature +100°C).

Zones for installation of explosion-proof electric actuators and conditions for equipment installation are defined in the following standards:

- EN/IEC 60079-10: Electrical apparatus for explosive gas atmospheres
Part 10: Classification of hazardous areas
- EN/IEC 60079-14: Electrical apparatus for explosive gas atmospheres
Part 14: Electrical installations in hazardous areas

Non-electric parts of electric actuators are designed, engineered, manufactured, tested and identified in compliance with the requirements for safety of machinery according to the following standards:

- EN 1127-1: Explosive atmospheres – Explosion prevention and protection
Part 1: Basic concepts and methodology
- EN 13463-1: Non – electrical equipment potentially explosive atmospheres
Part 1 : Basic method and requirements
- EN 13463-5: Non – electrical equipment potentially explosive atmospheres
Part 5: Protection by constructional safety "c"

Equipment identification consists of the following characters:

Ex - electric equipment complies with standard EN/IEC 60 079-0 and related standards for the corresponding types of explosion protection.

db - identification of the explosion **protection type** - "flameproof enclosure" according to EN/IEC 60 079-1.

eb - identification of the explosion **protection type** – „increased safety" according to EN/IEC 60 079-7.

tb - identification of dust ignition protection by enclosure „t" according to EN/IEC 60 079-31.

II or III - identification of the class of non-explosive electric device according to the standard EN/IEC 60 079-0.

C or D-identification of the sub-class II of non-explosive electric devices according to the standard EN/IEC 60 079-0.


T5 resp. T100°C - identification of the temperature class of non-explosive electric device class II or III according to the EN/IEC 60 079-0.

Gb - (EPL Gb) identification of the equipment designated for explosive gaseous atmospheres, with "high" level of protection, which is not a source of initiation in standard operation or in case of expected failures.

Db - (EPL Db) - identification of the equipment designated for explosive dust atmospheres, having a "high" level of protection, which is not a source of ignition in normal operation or during expected malfunctions.

1.4 Data specified on electric actuator

Nameplate:




Warning plate:




Nameplate contains the basic data concerning identification, performance and electricity: indication of producer, type, serial number, max. load torque and switching-off torque, operating speed, protection code, number of revolution, supply voltage and current.

Warning label:

- with identification of the waiting time and requirements for strength of screws.



Non-explosive label: identifying the manufacturer, certificate number, type identification, version identification, serial number and version for ambient temperature -25°C to +55°C or -50°C to +40°C or -60°C to +40°C.



Graphic symbols on electric actuator

The graphic symbols used on electric actuator substitute the text messages. Some of them are in accordance with EN ISO 7010, ISO 7000 and IEC 60417 within valid edition.



Dangerous voltage

(EN ISO 7010-W012)



Stroke of the electric linear actuator



Switching-off torque



Manual control

(0096 ISO 7000)



Protection terminal

(5019 IEC 60417)

1.5 Terminology

Potentially explosive environment - an environment where explosive atmosphere can occur.

Explosive gas atmosphere - a mixture of flammable substances (in form of gases, vapors or mist) with air under atmospheric conditions, which upon initiation enables the propagation of the combustion in unconsumed mixture.

Maximum surface temperature - maximum temperature occurring during operation in most adverse conditions (but within accepted tolerance limits) at any part of the surface of the electric device, that could result in ignition of the surrounding atmosphere.

Enclosure - all walls, doors, covers, cable glands, shafts, rods, draw bars, etc., that contribute to the level of protection against explosion or to the level of protection (IP) of the electric device.

Flameproof enclosure "db" - type of protection wherein the parts capable of igniting an explosive atmosphere are located within the enclosure, in case of explosion of an explosive mixture within the enclosure, such enclosure will withstand the pressure of the explosion and prevent the propagation of explosion to the surrounding atmosphere.

Increased safety "eb" - type of protection applied to electrical apparatus in which additional measures are applied so as to give increased security against the possibility of excessive temperatures and of the occurrence of arcs and sparks in normal service or under specified abnormal conditions.

Dust ignition protection by enclosure "tb" - type of protection for explosive dust atmospheres where electrical equipment is provided with an enclosure providing dust ingress protection and a means to limit surface temperatures.

Combustible dust - finely divided solid particles, 500 µm or less in nominal size, which may be suspended in air, may settle out of the atmosphere under their own weight, may burn or glow in air, and may form explosive mixtures with air at atmospheric pressure and normal temperatures.

Conductive dust - combustible dust with electrical resistivity equal to or less than $10^3 \Omega \cdot m$.

Combustible flyings - solid particles, including fibres, greater than 500 µm in nominal size which may be suspended in air and could settle out of the atmosphere under their own weight.

1.6 Instructions for stuff training

Requirements for specialized skills of persons performing assembly, operation and maintenance



Electric connection can be performed only by an acquainted person, i.e. an electrical engineer with professional education of electrical engineering at an apprentice school or a technical school (secondary, complete secondary or university education) and whose qualification was verified by an educational facility authorised to verify professional qualification.



Service can be performed only by workers professionally qualified and trained by the producer or contracted service centre!

1.7 Warning for safety use



1. Products are assigned for operation in environments consist from gases, steams and vapours or with flammable conductive dusts, temperature range from -25°C up to $+55^{\circ}\text{C}$; and special version for ultra low temperatures from -50°C up to $+40^{\circ}\text{C}$ or -60°C to $+40^{\circ}\text{C}$ with pressure range from 0.8 to 1.1 bar. EA can be installed at areas specified as zone 1, zone 2 resp. zone 21, zone 22.

It matters about following products are designated for enviroment:

- group **II**
 - the category **2**
 - for type of the atmospheres **G** or **D**
 - subgroup **C**
 - temperature class **T5**.
2. Products are designed according to standards for electrical and non-electrical devices assigned for areas with danger of explosion:
 - for electric parts: EN/IEC 60079-0, EN/IEC 60079-1, EN/IEC 60079-7 and EN/IEC 60079-31.
 - for non-electric parts: EN 1127-1 , EN 13463-1 and EN 13463-5.
 3. The maximum surface temperature of the actuator for given group T5 is not allowed to exceed $+100^{\circ}\text{C}$.
 4. If the actuator is placed on device which regulate medium with higher temperature than $+55^{\circ}\text{C}$, protect the actuator by additional construction in order to maintain ambient temperature max. $+55^{\circ}\text{C}$ and also to stop temperature transmitting through junction component!
 5. Cable glands blinds are assigned only for transport and storage period, i.e. for period till the actuator is builded into operation with danger of explosion, than blinds must be replace by connecting cable.
 6. If any of the cable glands are not used to install a cable, it must be replaced with certified Ex plug of the approved type, secured with WEICONLOCK AN 302-43 adhesive.
 7. Temperature on entry cables is max. 90°C .
 8. **ATTENTION: THE COVER CAN BE REMOVED 60 MIN. AFTER POWER SUPPLY IS SWITCHED OFF! USE SCREWS WITH A TENSILE STRENGTH $\geq 700 \text{ N/mm}^2$.**
 9. **WARNING – POTENTIAL ELECTROSTATIC CHARGING HAZARD.**

During operation of EA it must be prevented any process with intensive formation of electrostatic charge stronger than manual friction of his surface.

Product protection

EA **UM 2-Ex** does not have own short-circuit protection, therefore there must be included suitable protective device into the supply power (circuit breaker, or fuse), which serves at the same time as main switch. For protection, we recommend to use a fuse type "T" or a contactor type "C".

Type of equipment from a connection point of view: The equipment is designed for permanent connection.

1.8 Warranty conditions

The supplier is responsible for completeness of the delivery and guarantees these specifications of the product which are stated in the Contract.

The supplier is not responsible for any deterioration of parameters caused by the customer during storage, unauthorised installation or improper operation.

1.9 Under-guarantee and after-guarantee service

Our customers are provided with professional service of our firm in installation, operation, service, maintenance, revision and help in troubleshooting for all our products.

Under-guarantee service is performed by the service department of the production plant, or by a contracted service centre according to a written claim.

In case of occurring of any fault please let us know it and state:

- type code
- serial number
- ambient parameters (temperature, humidity...)
- duty cycle including frequency of switching
- type of switching-off (position or torque)
- set switching-off torque
- type of fault - description of claimed fault
- it is recommended to place also Installation certificate.

It is recommended to have **after-guarantee service** performed by the service department of the production plant, or by a contracted service centre, with national laws.

1.9.1 Lifetime of actuators

The lifetime of an electric actuator (EA) is at least 6 years.

EA used for closing mode (closing valves) comply with the requirements for at least **15,000 working cycles** (cycle C – O – C at 30 revolutions per operating stroke:for multi-turn EA)

EA used for regulating/modulating operation (control valves) comply with the below stated numbers of **operating hours** at the total number of 1 million start-ups:

| Switching frequency | | | | |
|---|--------------------------|------------------------|------------------------|------------------------|
| max. 1,200 [h ⁻¹] | 1,000 [h ⁻¹] | 500 [h ⁻¹] | 250 [h ⁻¹] | 125 [h ⁻¹] |
| Minimal lifetime expectancy – number of operating hours | | | | |
| 850 | 1,000 | 2,000 | 4,000 | 8,000 |

Time of **net operation** is min. 200 hours, max. 2,000 hours.

Lifetime at operating hours depends on loading and switching frequency.

Note : High switching frequency does not ensure better regulation. Setting of regulation parameters should be therefore made with the inevitably necessary switching frequency needed for the process in question

1.10 Operation conditions

1.10.1 Product location and operation position

EA may be installed and operated in enclosed locations of industrial facilities with no temperature and moisture regulation, protected from direct climatic effects (such as direct sunlight). Moreover, special “marine” versions may be used in waste water treatment applications, water management, selected chemical applications, tropical environments and coastal areas.

Warning:



Actuator installed on the open place must be protected against a direct climate effects by shelter.

Installation and operation of EA is possible in **any position**. Vertical position of output part axis and with the control part above the valve is usual.

1.10.2 Working environment

According to valid standard IEC 60 721-2-1, there are delivered these versions of electric actuators:

- 1) Version „standard“ for type climate temperate
- 2) Version „tropical wet“ for type climate tropical wet
- 3) Version „cold“ - for type climate cold
- 4) Version „tropical dry and dry“ for type climate tropical dry and dry
- 5) Version „marine“ for type climate marine
- 6) Version „arctic“ for type climate arctic.

In accordance with IEC 60 364-1, IEC 60 364-5-51 within valid edition the EA have to resist external effects and operate reliably:

In the conditions of the following types of environment:

- warm mild to very hot dry with temperature in range -25°C to +55°CAA 7*
- cold to warm mild and dry with temperatures in range -50°C to +40°CAA 8*
- cold to mild hot dry with temperatures in range -60°C až +40°C AA 1*+AA 5*
- with relative humidity 10 to 100 %, including the condensation of up to 0,029 kg water content per 1 kg of dry air, at above stated temperatureAB 7*
- with relative humidity of 15÷100%, including the condensation of up to 0,036 kg water content per 1 kg of dry air, at above stated temperatureAB 8*
- with relative humidity 5 to 100 %, including the condensation of up to 0,025 kg water content per 1 kg of dry, at above stated temperature AB 1*+AB 5*
- with elevation up to 2000 m, with barometric pressure range from 86 kPa up to 108 kPa AC 1*
- with exposure to intensive water jets (IPx6) AD 6*
- with submersion – (product with enclosure IPx8)..... AD 8*
- with strong dustiness – with a possibility of influences of inflammable, non-conducted and non-explosive dust; the middle layer of dust; the dust drop more than 350 but not more than 1000 mg/m² per day (products with protection enclosure of IP 6x).....AE 6*
- expose to corroding or pollute chemical substances during producing or using of these substances); at places where is handled with small quantity of chemical products and these can accidentally get in contact with an electric device AF 3*
- with permanent exposure of big amount of corroding or contaminated chemical and salt fog in execution for sea environment, fog sewage water disposal plant and some chemical plant AF 4*
- with a possibility of influences of mechanical stress:
 - medium sinusoid vibrations with frequency in range from 10 up to 150 Hz, with shift amplitude of 0,15 mm for $f < f_p$ and acceleration amplitude 19,6 m/s² for $f > f_p$ (transition frequency f_p is from 57 up to 62Hz)AH 2*
 - medium impacts, shocks and vibrations AG 2*
- with serious danger of plants and mould growingAK 2*
- with serious danger of animal occurrence (insects, birds, small animals) AL 2*
- with detrimental influence of radiation:
 - of stray current with intensity of magnetic field (direct or alternate, of mains frequency) up to 400A.m⁻¹AM2-2*
 - of sun radiation with intensity > 500 and ≤ 700W/m² AN 2*
- with effects of medium seismic activity with acceleration > 300 Gal ≤ 600 GalAP 3*
- with direct endanger by storm AQ 3*
- with quick air movement and strong wind AR 3 , AS 3*
- stand on a conductive bottom) BC 3*
- with a danger of inflammable gases and vapours explosion - for Ex of version BE 3N2*
- fire risks BE 2*

* Marking in accordance with IEC 60364-1, IEC 60 364-5-51 and IEC 60 364-5-55 within valid edition

1.10.3 Power supply and duty cycle

Power supply:

electric motor.....24 V AC/DC; 120 V AC, 230 resp. 220 V AC; 3x400 resp. 3x380 resp. 3x415 V AC ±10%.

control..... 24 V AC resp. 220-240 V AC ±10%

Power supply frequency.....50 Hz, or 60**Hz ± 2 %

** Rotation speed will increase 1,2 times, and torque will decrease 1,2 times

Duty cycle - according to EN/IEC 60034-1 within valid edition:

EA UM 2-Ex are designed for **remote control**:

- short-time operation S2-10 min
- intermitted operation S4-25%, max. 90 cycles per hour

EA with controller are designed for **automatic regulation**:

- intermitted operation S4-25%, 90 up to 1200 cycles per hour

Note:

1. Duty cycle consist of load type, load factor and switching rate.
2. Once EA is connected to the external controller unit, also use it as a control EA where the max. load torque reaches the 0.7 multiple of the maximum loading torque for remote operated EA UM 2-Ex

1.11 Packing, transport, storing and unpacking

Surfaces without surface treatment are treated by conservation preparation MOGUL LV 2-3 before packaging .

Conservation is not necessary if the following storage conditions are complied with:

- Storage temperature: -10 to +50 °C
- Relative air humidity max.80 %
- Electric actuators and their accessories must be stored in dry, well ventilated covered spaces, protected against impurities, dust, soil humidity (by placement to racks, or on palletes), chemicals and foreign interventions
- There shall be no corrosive gases present in the storage areas.

The of **UM 2-Ex** are delivered in solid packages guaranteeing resistance in accordance with EN/IEC 60 654. Package is a box. Products in boxes is possible to load on the pallets (pallet is returnable). On the outer side of the package is stated:

- manufacturer label,
- name and type of product,
- number of pieces,
- other data – notices and stickers.

The forwarder is obliged to secure packed products, loaded on transportation means, against self-motion; if open transportation means are used, to secure their protection against atmospheric precipitations and splashing water. Displacement and securing of products in transportation means must provide their stable position, exclude the possibility of their inter-collision and their collision with the vehicle walls.

Transportation can be executed by heatless and non hermetic spaces of transportation vehicles with influences within the range:

- temperature: -25°C up to +50°C (a strange version –50 ° C up to +45 ° C)
- humidity: 5 up to 100 %, with max. water content 0.028 kg/kg of dry air
- barometric pressure 86 up to 108 kPa

After receiving EA check whether during transport or storage the actuator was not damaged. Compare also whether the parameters on their nameplates are in accordance with accompanying documentation or the Contract. If any discrepancy or fault occur inform immediately your supplier.

If the actuators and accessories are not immediately installed, they have to be stored in dry, well-ventilated sheltered rooms, protected against dirt, dust, soil humidity (with placing onto shelves or onto pallets), chemical impacts and encroachment, at ambient temperature from -10°C up to +50 °C and relative humidity max. 80 %, in special version at temperature –50°C do +40°C.

- It is forbidden to store EA outside or in areas not prevented against direct impact of climate.
- Strains of the surface finishing should be promptly removed if any – it can prevent the product against corrosion damages.
- While storing more than one year it is necessary to check lubrication filling before the actuator is put into operation.
- The EA installed but not operated are to be protected the same way as when storing (e.g. with a wrapping).
- After it is mounted onto a valve in free and wet areas or in areas where temperature is changing it is necessary to connect the space heater – to prevent the actuator against corrosion resulted from water condensed in the control part.
- Remove odd conservation grease as late as before putting into operation.

1.12 Assessment of the product and packaging and removal of contamination

The product and its package are made of recycling materials. Do not throw the single parts of the package and of the product after their life but sort them according to instructions in corresponding executives or regulations of environment protection, and allow their recycling.

The product and its packing are not a source of any environment pollution or contamination and do not contain any dangerous waste.

2. Description, function and specifications

2.1 Description and function

EA **UM 2-Ex** are of compact construction. They are composed of two functionally different main parts.

The **gear part** is made up by a flange with a connecting part resp. linear mechanism for connection onto a controlled device, and gears placed in the bottom; on the other side drive mechanisms for control part units are surfaced.

The **control part (Fig. 1, 1a)** is placed on a control board (1) consisting of:

- electric motor (2) (at single-phase version with capacitor)
- torque unit (5) (controlled with a worm axial shift)
- position-signaling unit (3) with a position transmitter (6) and with a mechanical local position indicator (4)
- space heater (8) with thermal switch (7)
- electronic module (9)
- electrical connection through terminal boxes (10), located in the control area and cable glands Ex d version with direct entry with compound filling around cable cores
- **relays of torque switch S1 or S2 (ReS11, ReS12) (12)** – customized version

Additional accessories:

Manual control: made up by a hand wheel with a worm gearing.

Electric local control




Fig.1




Fig.1a

2.2 Basic specifications

Basic EA specifications:

are given in Table 1.

Table 1: Basic EA specifications

| Type number | Operating speed 2) | | Number revol. | Max. load torque | Switching-off torque ±10 [%] | Weight | Electric motor 1) | | | | | | | | |
|-----------------------------------|-----------------------|-------|---------------|------------------|---------------------------------|----------|----------------------|---------------------------------|------------------------------------|-----------|---------|----------------------|-------------------|-------|--|
| | | | | | | | Power supply voltage | | Nominal | | | Capacitor capacity.. | | | |
| | | | | | | | | | power | speed | current | | | | |
| | | | | | | | | | | | nominal | | starting ±20 % | | |
| [1/min] | | [rev] | [Nm] | [Nm] | [kg] | [V] | [W] | [1/min] | [A] | [μF/V AC] | | | | | |
| 50Hz 60Hz | | | | | | | | | | | | | | | |
| UM 2-Ex type number 137 | 10 | | see Table 3 | 68 | 45-80 | 20 až 24 | Single-phase | 230 (220) | 120 | 2600 | 1,0 | 1,9 | 8/450 | | |
| | 15 | | | 46 | 30-60 | | | | | | | | | | |
| | 20 | | | 34 | 24-40 | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| | 10 12 | | | | 68 | | 45-80 | Single-phase | 120 60Hz | 120 | 3100 | 2,0 | 3,8 | 8/450 | |
| | 15 18 | | | | 46 | | 30-60 | | | | | | | | |
| | 20 24 | | | | 34 | | 24-40 | | | | | | | | |
| | | | | | | | | | | | | | | | |
| | 10 | | | | 68 | | 45-80 | Single-phase/ Direct current | 24 AC/DC | 100 | 3350 | 4,9 | - | - | |
| | 15 | | | | 46 | | 30-60 | | | | | | | | |
| | 20 | | | | 34 | | 24-40 | | | | | | | | |
| | | | | | | | | | | | | | | | |
| | 10 | | | | 85 | | 60-100 | Trojfázové | 3x400 (3x380) resp. 3x415 | 180 | 2650 | 0,6 | 2,4 | - | |
| | 15 | | | | 68 | | 48-80 | | | | | | | | |
| | 20 | | | | 51 | | 36-60 | | | | | | | | |
| | 40 | | | | 25,5 | | 18-30 | | | | | | | | |

1) Switching elements for different type of load (also for EA) defines standard EN/IEC 60 947-4-1.

2) Anomaly of operating speed ±10% at 230 V resp. 220 V AC, 3x400 resp. 3x380V resp. 3x415 V AC.

Additional technical data:

EA protection enclosure: **IP 66/68** (EN/IEC 60529 within valid edition)

According to definition for EA, enclosure IP68 fulfills following requirements:

-water column max. 10m

-time of continuous submersion in water max. 96 hours

Mechanical ruggednesssee chapter 1.7.2 Working environment, code AH 2

Self-locking: the EA is self-locked

Electric motor protection: with thermal switch

EA braking: by roller bief

Output part backlash:..... max.5 ° at load of 5%-of maximum torque

Electric control:

- remote control (the output element of the EA is controlled with supply voltage), resp. by feeding of unified signal

Adjustment of the limit positions:

The limit position switches are set to the number of work turns with accuracy of $\pm 90^\circ$.

Additional position relays (S5,S6) are adjustmentcca 1 rev. beneath the limit switches

Tandem position relays are adjustment..... just before the end positions

Hysteresis of position switches.....max. 180°

Unless the customer specifies the value of the particular working revol., revol. are set to **5st stage** of the selected stroke order – see Table 3.

Adjustment of the torque switches:

If other adjustment not specified the switching torque is set to the maximum value with tolerance of $\pm 10\%$.

Switches (S1, S2, S3, S4, S5, S6, S13, S14):

Type **DB 6: silver contacts** – standard version

Switches:

Silver microswitches – DB 6:

voltage 250 V(AC); 50/60 Hz; 20 mA to 2 A; $\cos\phi = 0.6$;

24 V(DC) and 48 V DC; 20 mA to 1 A; $T=L/R=3\text{ms}$;

min. switching voltage 20V.

Gold switches – DB 3

max. 250 V AC; 1 mA to 0,1(0,05)A;

24 V DC and 48 V DC, 1 mA to 0,1 A ; $T=L/R=3\text{ms}$.

Relay thrust of switch S1, resp. S2 (ReS11, ReS12):

Model **RT 424**

- 250 V AC, 8 A; 24 VDC, 8 A; max. switching-on power AC 2000 VA

Space heater (E1)

Space heater - supply voltage: corresponding with motor supply voltage (max. 250 V AC)

Heating power: cca 40 W/55 °C

Switching resistorthermal switch

Thermal switch of space heater (F2)

Supply voltage: corresponding with motor supply voltage (max. 250V AC)

Switching-off temperature:..... $+20^\circ\text{C} \pm 3\text{K}$

Switching-on temperature:..... $+30^\circ\text{C} \pm 4\text{K}$

Manual control:

By handwheel after unscrewing the locking screw . Rotate the handwheel clockwise to move the output shaft in the direction „Z“.

Position transmitters

Resistive position transmitter

| | |
|--|---|
| Resistance (single B1) | 100; 2 000 Ω |
| (double B2) | 2x100 Ω, 2x2000 Ω |
| Operating life of transmitter | 1.10 ⁶ cycles |
| Load capacity | 0,5 W do 40 °C, (0 W/125°C) |
| Maximum current of sliding contact | max.35 mA |
| Maximum supply voltage..... | $\sqrt{P \times R}$ V DC/AC |
| Potentiometer linearity error | ±2,5 [%] ¹⁾ |
| Potentiometer hysteresis | max. 2,5 [%] ¹⁾ |
| Potentiometer values at limit positions: | "O" (open)..... ≥ 93%, "Z" (closed)..... ≤ 5% |

Capacitive (B3): non-contact, life 10⁸ cycles

2-wire connection with built-in power supply or without built-in power supply

The current signal **4 ÷ 20 mA** (DC) is acquired from the capacitive transmitter supplied from the internal or an external voltage supply source. The electronics of the transmitter is protected against eventual wrong polarity and current overloading. The entire transmitter is galvanic insulated so several transmitters can be connected to one external voltage source.

| | |
|---|---------------|
| Power supply voltage (with power supply) | 24 V DC |
| Power supply voltage (without power supply) | 18 to 28 V DC |
| Ripple voltage | max. 5% |
| Max power input | 0,6 W |
| Load resistance | 0 to 500 Ω |
| Load resistance can be single side grounded. | |
| Influence of resistance on output current | 0,02%/100Ω |
| Influence of voltage on output current..... | 0,02%/1V |
| Temperature dependency | 0.5% / 10 °C |
| Output signal values at limit positions: | |

 "O"

 "Z"

Values tolerance of output signal of EPV

 "Z"

 "O"

DCPT2 – current transmitter (B3)

- **2-wire connection** without built-in power supply or with built-in power supply

| | |
|---|--|
| Current signal | 4 ÷ 20 mA (DC) with optional mirroring (20 ÷ 4 mA) |
| Mode of operation..... | contactless, magnetic resistance |
| Transmitter increments without gears | 0.352 ° |
| Loading resistor: | 0 through 500 Ω |
| Operating stroke | 35 to 100% of the rated stroke at the gear ratio |
| Non-linearity..... | max. ±1 % |
| Non-linearity - geared | max. ±2.5 % |
| Power supply voltage for version without power source | 15 through 28 V DC, max.42 mA |
| Power supply voltage for version with built-in power source | 24 V DC |
| Operating temperature..... | -25 to +70°C |
| Linearity deviation:..... | ±2.5 % ¹⁾ |
| Hysteresis | max. 2.5 % ¹⁾ |
| Error messages | by flashing LED |

1) from rated value of transmitter referred to output values

Electronic positional transmitter (EPV) - converter R/I (B3)**2-wire version, resp. 3-wire (without built-in power supply, or with built-in power supply)**

| | |
|--|--|
| Output signal for 2-wire version | 4 ÷ 20 mA (DC) |
| Output signal for 3-wire version | 0 ÷ 5 mA (DC) |
| | 0 ÷ 20 mA (DC) |
| | 4 ÷ 20 mA (DC) |
| Power supply voltage for 2-wire version without built-in power supply | 15 to 30 V DC |
| Power supply voltage for 2-wire version -with built-in power supply | 24 V DC ± 1,5% |
| Load resistance for 2-wire version | max. $R_L = (U_n - 9V) / 0,02A$ [Ω] (U_n – voltage [V]) |
| Power supply voltage for 3-wire version | ±1,5 % |
| Load resistance for 3-wire version | max. 3 k Ω |
| Temperature dependency | max. 0,020 mA / 10 °C |
| Output signal values at limit positions on the terminal 81,82 | „O“ 20 mA (5 mA, 10 V) |
| | „Z“ 0 mA (4 mA, 0 V) |
| Values tolerance of output signal | „Z“ +1,5 % ¹⁾ |
| | „O“ ±1,5 % ¹⁾ |
| Linearity deviation | ±2,5 % ¹⁾ |
| Hysteresis | max. 2,5 % ¹⁾ |

1) from rated value of transmitter referred to output values

Lubricators :

- see chapter Maintenance - extent and periodicity

2.2.1 Mechanical connection

– flange (ISO 5210), pillars

Basic and connecting dimensions are given in dimensional drawings.

2.2.2 Electrical connection

Terminals (X) for EA UM 2-Ex - max. 32 screw-less terminals with connecting wire cross-section of 0.08 to 2.5 mm², wire stripping length of the wires for screwless terminals is from 8 to 9mm.

For non-armored cables - as standard (temperature on entry of cables is max. 90°C):

UM 2-Ex:

- 1 cable gland - 1xM16x1,5 ($\varnothing D = 3,2$ to 8,7 mm);
- 1 cable gland - 1xM16x1,5 ($\varnothing D = 6,1$ to 11,7 mm);
- 1 cable gland - 1xM16x1,5 ($\varnothing D = 6,5$ to 14,0 mm);

For armored cables - upon special order:

UM 2-Ex:

- 1 cable gland - M20x1,5 ($\varnothing D = 3,1$ to 8,6 / $\varnothing D_1 = 6,1$ to 13,4 mm);
- 1 cable gland - M20x1,5 ($\varnothing D = 6,1$ to 11,6 / $\varnothing D_1 = 9,5$ to 15,9 mm);
- 1 cable gland - M20x1,5 ($\varnothing D = 6,5$ to 13,9 / $\varnothing D_1 = 12,5$ to 20,9 mm);

$\varnothing D$ = connecting cable diameter

$\varnothing D_1$ = outside diameter of the connecting cable with armoring

Table 2: Association of the cable diameter with cable glands type

| Version | | Thread | Type cable | | Encapsulation of cable ¹⁾ | Inside/ outside diameter of cable |
|---|--|---------------------|-------------------------------------|-----------------------------|--------------------------------------|-----------------------------------|
| | | | non-armored cables and not shielded | armored cables and shielded | | |
| CMP / Stahl | X-20S/16-A2F- M16 | M16x1,5 | x | | b) | 3,2 - 7,0 resp. 5,0 - 10,0 |
| | X-20S/16-A2F- M20 | M20x1,5 | | | | 3,2 - 8,7 / - |
| | X-20S-A2F- M20 | | | | | 6,1-11,7 / - |
| | X-20-A2F- M20 | | | | | 6,5-14,0 / - |
| | X-20S/16-T3CDS-M20 | | | x | b) | 3,1-8,6 / 6,1-13,4 |
| | X-20S- T3CDS-M20 | | 6,1-11,6 / 9,5-15,9 | | | |
| | X-20- T3CDS-M20 | | 6,5-13,9 / 12,5-20,9 | | | |
| | X-16s-PXSS2K- M16 | M16x1,5 | x | | b) | 3,2-8,7 |
| | X-16-PXSS2K- M16 | M20x1,5 | | | | 6,1-11,7 |
| | X-20s/16-PXSS2K - M20 | | | | | 3,2-8,7 |
| | X-20s-PXSS2K - M20 | | | | | 6,1-11,7 |
| | X-20-PXSS2K - M20 | | | 6,5-14,0 | | |
| | X-16s-PX2K-M16 | M16x1,5 | x | | a) | 3,1 – 8,7 / 6,1-11,5 |
| | X-16-PX2K-M16 | M20x1,5 | | | | 6,5-14,0 / 12,5-20,9 |
| | X-20s/16-PX2K-M20 | | | | | 3,1-8,6 / 6,1-13,4 |
| | X-20s-PX2K-M20 | | | | | 6,1-11,6 / 9,5-15,9 |
| X-20-PX2K-M20 | 6,5-13,9 / 12,5-20,9 | | | | | |
| | | | | | | |
| Pflicht / Peppers | 12.20..13CR.exd / CR ^{****} 16 | M20x1,5 | | x | b) | 3,4 – 8,4 / 9,0-13,5 |
| | 12.20..16CR.exd / CR ^{****} 20S | | 7,2-11,7 / 12,9-16,0 | | | |
| | 12.20..21CR.exd / CR ^{****} 20 | | 9,4-14,0 / 15,5-21,1 | | | |
| | 15.20d13CRCexd / CR-C ^{***} 16 | | x | a) | 9,0-11,7 / 9,0-13,5 | |
| | 15.20d16CRCexd / CR-C ^{***} 20S | | | | 10,4-11,7 / 11,5-16,0 | |
| 15.20d21CRCexd / CR-C ^{***} 20 | 12,5-14,0 / 15,5-21,1 | | | | | |
| Hawke | ICG 623/Os/M20 | | x | | a) | 3,0-8,0 / - |
| | ICG 623/O/M20 | | | | | 7,5-11,9 / - |
| | ICG 623/A/M20 | | | | | 11,0-14,3 / - |
| | 501/453/Os/ M20 | | x | | b) | 3-8 / 5,5-12 |
| | 501/453/O/ M20 | 7,5-11,9 / 9,5-16 | | | | |
| | 501/453/A/ M20 | 11-14,3 / 12,5-20,5 | | | | |
| | ICG 653/UNIV/Os/M20 | a) | | | 8,9 / 5,5-12,0 | |
| | ICG 653/UNIV/O/M20 | | | | 8,9 / 9,5-16 | |
| ICG 653/UNIV/A/M20 | 11 / 12,5-20,5 | | | | | |

¹⁾ Encapsulation of cable:

- a) - Barrier glands – type of gland with Compound (Barrier) Seal
- b) Sealing of cable core using the filling compound see section 3.1.2 Cable routing and connection

Table 3: Wire cross-section conversion table (mm² – AWG)

| Wire cross-section conversion table (mm ² – AWG) | |
|---|---------|
| Wire cross-section | |
| mm ² | AWG |
| 0,05 | 30 |
| 0,2 | 24 |
| 0,34 | 22 |
| 0,5 | 20 |
| 0,75 | 18 |
| 1,5 | 16 |
| 2,5 | 14 |
| | |
| Tightening torque conversion table (N.m – lbs.-in) | |
| Tightening torque | |
| N.m | lbs.-in |
| 0,2 | 2,7 |
| 0,3 | 4 |
| 0,5 | 7 |

Protective terminal:

Upon start-up in operation - at equipment installation:

- for safe use of the actuator it is necessary to connect the outside and inside grounding terminal. The position of the outside and inside grounding terminal can be seen in Fig. 1c and Fig. 1d. HP3 insulated eyelet crimping pliers should be used to crimp wire to the outside grounding terminal (fy CEMBRE).

Outside and inside earth terminal are mutually interconnected and identified with a protective grounding symbol.

There must be power switch or motor circuit breaker included to the power supply which must be placed as close as possible to the device, easily accessible to the operator and marked as an disconnecting device of actuator.

The electrical connection is made according to the wiring diagrams inserted or. glued to the top cover of the EA.


Product protection

To protect the product, we recommend using fuses or a suitable circuit breaker.

Table 4: Fuse values and characteristics


| Type | Order code | Voltage | Frequency (Hz) | Electric motor Power / Power input (W) | max. current EA (A) | Fuse values F3 |
|----------------|----------------|-----------|----------------|--|---------------------|-----------------|
| UM 2-Ex 137 | 137.X-0XXXX/YY | 230 VAC | 50 | 120/228 | 1,3 | T 1,6 A / 250 V |
| | 137.X-LXXXX/YY | 220 VAC | | | | |
| | 137.X-1XXXX/YY | 3x400 VAC | 50 | 180/300 | 0,82 | T 1,6 A / 250 V |
| | 137.X-2XXXX/YY | 3x415 VAC | | | | |
| | 137.X-MXXXX/YY | 3x380 VAC | | | | |
| | 137.X-NXXXX/YY | | | | | |

Electric connection: - according to the wiring diagram stuck into the case of the EA.



OUTSIDE
GROUNDING
TERMINAL

Fig.1c



INSIDE
GROUNDING
TERMINAL

Fig.1d

3. Installation and dismantling of actuator



Abide by safety measures!

Note:

Check again if placement of EA reply to chapter "Operation conditions". In case that operation conditions are different from recommended, consultation with producer is needed.

Before starting of mounting the EA onto the valve:

- Check again whether the EA was not damaged during storing.
- Check whether the adjusted operation stroke and connecting dimensions of the actuator (see the nameplate) are in compliance with the valve parameters.
- In case of inconsonance, perform adjusting according to the part "Adjustment".

3.1 Installation

EA is by the producer adjusted to parameters according to the nameplate.
Before installation put the hand wheel on.

3.1.1 Mechanical flange connection

- Defat the abutting areas of the connecting flange of the EA valve or the gear carefully;
- Lubricate the output shaft of the valve/gear with a grease not containing any acids;
- Set the EA to the limit position "closed", set the valve to the same position;
- Put the EA onto the valve with the output shaft reliably stalled in the valve coupling/gear;

Attention! Do not adjust EA on an armature forcibly because of damage of the gear!

- Use the hand wheel to turn the EA to fit the openings in the EA and valve flanges if needed;
- Check whether the connecting flange abuts with the valve/gear;
- Fix the flange with four screws (with mechanical strength min 8G) fixed the way the actuator can Be moved. Tighten the screws equally in cross;
- At the end check the correctness of the fixture with the valve with rotating the hand wheel.

3.1.2 Cable routing and connection

Direct entry to flameproof enclosure (compound filling around cable cores):

Cable glands system must comply with the requirements of EN 60 079 art.10.4.2 direct entry to class flameproof enclosure IIC.

Cable glands threads are secured against loosening by Loctite 243 adhesive.

Therefore during installation of the actuator the customer is required to **apply non-explosive sealing device** using a compound filling material and sealing tubes.

If any of the cable glands are not used to install a cable, it must be replaced with certified Ex plug of the approved type, secured with Loctite 243 adhesive.

Temperature on entry cables is max. 90°C.

Follow the following instructions when compound filling the cable glands:

- 1) Remove sufficient length of cable sheathing - minimum length of compound filling must be at least 20mm.
- 2) Apply silicone putty on individual cable core branching and to the cut edge of the sheathing to prevent overflowing of the filling compound during subsequent filling. Apply sealing tubes over cable cores and press the beveled inside edge to the cable sheathing.
- 3) Fill the tube with the cable core using the filling compound prepared according to the instructions.
- 4) After the compound has cured (about 24 hour) clean the cable under the tube. Remove the tightening nut, compression ring and sealing o-ring from the actuator cable glands and slip these parts over the cable. Route the cable through the body of the cable glands into the actuator and tighten the nut.
- 5) Connect individual wire cores to the terminals.

Advantage: in case of replacement or repair of the actuator, there is no need to cut the cable, it is just released from the cable glands.

Sealing of cable core using the filling compound:




Fig. 1e

3.1.3 Electric connection and checking of function

Follow up with connecting the EA with mains or master system.



1. Follow instructions in the part "Requirements for professional qualification"!
2. While laying electrical line abide by the instructions for heavy current installations. Power supply cables must be of the type approved. Minimum thermal resistance of power supply cables and wires must be +90°C.
3. Cables to terminal boards or connectors lead through screw cable glands.
4. Before initiation ES into operation internal and external protection terminals are needed to be connected.
5. Feeding cables are to be fixed to the solid construction at most 150 mm from the cable glands.
6. Torque switching is not fitted with mechanical interlocking device.
7. For proper EA functioning the torque (S1, S2) and position (S3, S4) limit switches must be serial connected into the electric motor control circuit – see the recommended connection for single phase electric motor (example connection 1) and for 3 - phase electric motor (example connection 2).
8. The output wires electric motor thermal protection must be connected into the electric motor control circuit on a such way that when the electric motor thermal protection opens (it means when the allowed electric motor winding temperature is exceeded) it will cause the disconnection of the electric motor supply voltage.

Connection with the terminal board:

Before the connection remove the actuator case and check whether the type of current, power supply and frequency correspond with the data on the actuator nameplate.



Electric connection:

- The electric connection should be realized according to the wiring diagram stuck into the case of the EA;
- The electric connection should be performed through two cable glands see No. 2.2.2.
- Once electrical services are completed put on the cover and fasten it evenly crosswise by bolts. Fasten the cable glands to ensure specified shielding.

Notes:

1. To connect the input control signals and output signals is needed to use shielded wires with steel wire braid (Galvanised Steel Wire Braid GSWB Ξ), for example cable type "Bruflex ® HSLCH", 4x0, 5 (company Bruns Kabel).
2. The EA are delivered with cable glands which in case of correct tighten are onto the supply lead allow the protection enclosure of IP 68.
3. The cable is to be fixed the way corresponding with its allowable bending radius not to damage or deform the sealing element of the cable lead. The supply leads have to be fixed onto a fixed construction max. 150 mm from the leads.
4. It is recommended to connect the remote transmitters with shielded wires.
5. The face areas of the control part cover should be clean before fixing it back.
6. The EA is reversible if the time interval between the power supply is switched off and on for the reverse direction of the output part motion is at least 50 ms.
7. The allowed delay after it is switched off, i.e. time from the switches reaction up to the motor without any voltage is 20 ms maximally.

Example of electric motor connection with position and torque switches.





Observe the valve manufacturer's instructions with respect to the requirement to ensure switching-off in limit positions through position or torque switches!

Caution:



1. Power supply to the actuator and connections with switching, protective and safety devices may be carried out only by personnel with appropriate qualification, in compliance with the corresponding standards and wiring diagrams, such as those specified in the Instruction Manual....
2. All terminal connections must be checked after connection of the power supply cables. The conductors must not apply any bending or tensile stress upon the connecting terminals. The following measures should be taken when using aluminum conductors:
3. Immediately before connecting the aluminum conductor, it is necessary to remove the oxide layer on the surface and prevent the oxidation by application of neutral vaseline to protect the connection.

After connection, check the correct direction of the actuator shaft rotation by short activation of the actuator in intermediate position. This can also be checked by using a stick made of insulating material to activate the corresponding micro-switch - limit, position or torque (depending on the type of actuator control) during operation of the actuator.

If the actuator does not stop, but stops upon signal from micro-switch corresponding to the opposite rotation direction, you will need to change the direction of rotation of the actuator output shaft. In case of an actuator driven by single-phase electric motor, the direction of rotation can be changed by switching the supply cables on the terminals of the electric motor.

In case of actuators with three-phase electric-motor, interconnect one of the pairs of conductors on terminals U, V, W of the actuator terminal board. Repeat the function test again.

Important!

- 1) During adjustment, repair and maintenance, secure the actuator by prescribed means in order to prevent its power-up resulting in the possibility of electric shock injury or injury by rotating parts.
- 2) When reversing the operation of actuators with single-phase electric motor, power supply must never be connected simultaneously to both outputs of the start-up capacitor at the same time, otherwise the capacitor could discharge through torque switch contacts resulting in their sticking together.

After adjustment of the actuator, check its operation using the control circuit. Especially make sure that the actuator starts-up correctly and that the electric motor is disconnected from power supply after triggering of the corresponding micro switch. Otherwise immediately disconnect the power supply to the actuator to prevent damage to the electric motor and try to locate the malfunction.

After the EA is electrically connected it is advised to **check functions:**

- After the EA is electrically connected to check the correct functions of the position and the torque switches S1 - S6 and if needed adapt the order of the single phase leads for the 3-phase electric motor.
- Set the valve manually into an mid-position.
- Connect the power supply to the terminal for supplying the EA in the direction "opening" and follow the direction of the output shaft of the actuator rotation. When EA is connected correctly, the output shaft of EA, into the actuator control part from the top, must rotate counterclockwisely. If not, it is necessary to change the phase leads L1 and L3 on the terminals 2 and 4 mutually, valid for 3-phase electric motor. After the exchange is made check the direction of the EA rotation.
- If any of the functions is not correct, check the switches whether they are wired properly according to the wiring diagrams.

3.2 Dismantling



Attention!

Before disassembly is necessary to disconnect electric supply of electric actuator!

Secure by prescribed way protection against connection of EA to the network and thus potential electrical accident!

- Disconnect the EA from mains.
- Disconnect the leads from the EA terminal boards and loosen the cables from cable glands. Pull out the connectors in case of the connector version.
- Loosen the fixing screws of the EA flange and coupling screws and disconnect the EA from the valve.
- While sending the EA to be repaired put it into a package solid enough to avoid damages of the EA during transportation.

4. Adjustment



Keep safety regulations! Follow the prescribed procedure to assure that the EA is not connected to mains when live not to cause any injury by electrical current!

The adjustment is performed with the EA mechanically and electrically connected and the connection and functions were checked. The chapter describes the adjustment of the EA to the parameters given in the nameplate in case that any of its parts is out of tune. The adjusting parts on Fig.1 and Fig. 1a.

Definition of the direction of movement:

- movement direction "close" - the output shaft of the actuator rotates in the clockwise direction when looking into the actuator control part from the top.

4.1 Adjustment of the torque unit

The switching - off torque are adjusted by the producer for both directions, i.e. for the direction "opening" (the torque switch S1) as well as for the direction "closing" (the torque switch S2) to the specified value with tolerance of $\pm 10\%$. If not stated else they are adjusted to the maximum rate.

Adjustment and setting of torque unit to different torque values is possible by torque unit cams adjustment. Switching-off torque can be reduced only. Torque reducing is done by cam screw releasing and turning this cam against a mark on torque unit shaft. Adjustment close to MAX mark means maximum torque. It is not allowed to go outside this mark. Adjustment close to MIN mark does not mean minimum torque, it is just an information about torque reducing direction.





Fig.2

Adjustment of position-signalling unit (S3(S13),S4(S14)) (Fig.6)

EA is delivered set to a stroke corresponding to 6th according to table 3 or to a stroke required by customer. The procedure for position switches setting, adjustment a new setting is as follows (Fig. 6, 7):

- Having the set screw of the gear unit wheel released, move the adjustable wheel to a required stage of the range (it means to a one corresponding accurately to the particular revolutions, or to the next higher one) according to table 3 and Fig.7. When moving the adjustable wheel, take care to achieve the proper meshing with the gear wheel of the subjected stage, and then tighten the set screw back.
- Move EA to the "open" position electrically or manually. If, with electric move, EA has been switched off by S3 switch (Fig. 6), insert a screwdriver into set screw (29), press it and rotate in the arrow direction until an appropriate cam opens S3 switch. Pull the screwdriver out (see notice 1) and continue in moving EA in the „open“ position.
- In the „open“ position, insert a screwdriver into set screw (29), press it and rotate in the arrow direction until an appropriate cam closes S3 switch. Pull the screwdriver out (see notice 1).
- Move EA to the "close" position electrically or manually. If, with electric move, EA has been switched off by S4 switch (Fig. 6), insert a screwdriver into set screw (28), press it and rotate in the arrow direction until an appropriate cam opens S4 switch. Pull the screwdriver out (see notice 1) and continue in moving EA in the „close“ position.
- In the „close“ position, insert a screwdriver into set screw (28), press it and rotate in the arrow direction until an appropriate cam closes S4 switch. Pull the screwdriver out (see notice 1).
- Having position switches adjusted, You may need (depends on EA accessories) to adjust signaling switches, and position indicator.
- *Notice 1: in the case that the set screw remains pressed notwithstanding the screwdriver is out (it means that disengaged gear wheels don't mesh each other), turn gently the set screw against the arrow direction without pressing it until the set screw releases back to its initial position.*
- *Notice 2: In the variant of the **EA equipped with the S13, S14 tandem position switches**, these switches are to be adjusted after having the setup of the S3 a S4 switches completed, it means the S3 switch must switch simultaneously with the S13 switch, and the S4 switch must switch simultaneously with the S14 switch.*
- *Notice 3: By revolutions and speed adjustment it is necessary to keep actuators working duty.*

| TABLE 3 | | | | | | |
|-----------------|--|-------------------|--------------------|-------------------|------------------|-------------------|
| STROKE STAGE | MAX. REVOLUTIONS OF EA UM 2-Ex if the customer doesn't specify a producer, EA will be set up to the 6.stage of stroke) Note: for CPT transmitter maximum revolutions according to RADA II. | | | | | |
| | STROKE LINE I | STROKE LINE II | STROKE LINE III | STROKE LINE IV | STROKE LINE V | STROKE LINE VI |
| 1.stage | 1,1 | - | - | 1 | - | - |
| 2. stage | 2 | 1,5 | 1,6 | 1,8 | 1,2 | 1,3 |
| 3. stage | 3,5 | 2,8 | 3 | 3,2 | 2 | 2,4 |
| 4. stage | 6,4 | 5 | 5,3 | 5,8 | 4 | 4,2 |
| 5. stage | 11,5 | 9 | 9,5 | 10,5 | 7 | 7,5 |
| 6. stage | 21 | 16 | 17,5 | 19,5 | 13 | 14 |
| 7. stage | 39 | 30 | 32 | 35 | 24 | 25 |
| 8. stage | 70 | 55 | 58 | 64 | 43 | 46 |
| 9. stage | 128 | 100 | 106 | 116 | 78 | 84 |
| 10. stage | 232 | 180 | 193 | 211 | 140 | 150 |
| 11. stage | 420 | 330 | 350 | 385 | 260 | 275 |



4.2 Signaling switches adjustment (S5,S6) (Fig. 8)

The signaling switches of EA are at producer preset to switch on about 10% before end positions provided the customer not specified otherwise. Before proceeding with signaling switches adjustment, S3, S4 end position switches must be adjusted according to the previous chapter if necessary. The procedure of signaling switches adjustment is as follows:

- Check that the adjusting wheel of the signalling gearbox is adjusted to the required level of the stroke scope.
- Bring EA to a position in which You want S5 switch to close when EA is running in the „open" direction.
- Turn cam (31) of S5 switch (27) clockwise until S5 switch closes.
- Bring EA to a position in which You want S6 switch to close when EA is running in the "close" direction.
- Turn cam (30) of S6 switch (26) counterclockwise until S6 switch closes.

Notice: This signaling is capable to signalise from 50 up to 100 %..of the working stroke in both movement directions. With switch reversing function, a signaling capability from 0 up to 100 % is available.




Fig.8

4.3 Position indicator adjustment (Fig.8)

The position of the output member relative to the end positions of EA stroke is indicated by a mechanical position indicator.

- Before starting to adjust the position indicator, S3 and S4 position switches must be adjusted if required.
- The procedure of position indicator adjustment is as follows :
- Bring EA to the „closed“ position.
- Turn the position indicator disc (32) to bring a mark identified with a symbol for the „close“ direction in coincidence with a mark on the upper cover aperture (If it is difficult to turn the wheel, release the screw using the screwdriver to fix the wheel).
- Bring EA to the „opened“ position.
- Turn the upper part of the position indicator disc (32) to bring a mark identified with a symbol for the „open“ direction in coincidence with the mark on the upper cover aperture.

4.4 Adjustment of resistant transmitter (Fig.9)

The **resistant transmitter** is in the EA used to function as a remote position indicator.

Before the resistant transmitter adjustment the position switches have to be adjusted (S3,S4). Adjustment consists in setting of the resistance in the defined limit position of the EA.

Notes:

In case that the EA is unused within the complete operating speed range following the angle selected on the particular stroke line, the "Open" limit position resistance value will un-dergo proportional reduction.

The transmitters are used with resistance according to the customer's specification. With EA of 2- wire converter a transmitter of 100 W resistance is used .




Fig.9

To adjust the transmitter follow these steps:

Loosen the fixing screws (9) of the transmitter holder and push the transmitter out of mesh.

Put the actuator to the position "closed" (with the handwheel, until the corresponding position switch S2 or S4 switches).

Connect a meter for resistance measuring to the terminals 71 and 73 . Merací prístroj na meranie odporu pripojte na svorky 71 a 73 svorkovnice ES pri odpojenom napájacom napätí do ES.

Rotate the transmitter shaft (11) until resistance of $\leq 5\%$ of the nominal transmitter resistance can be read on the meter.

In the position put the transmitter to mesh with the drive wheel and fix the fixing screws on the transmitter holder.

Please check the resistance value in both of the final positions and in case of need repeat the procedure. Once the device is adjusted in a correct way disconnect the meter from the terminal.

4.5 Adjustment of the Electronic Position Transmitter (EPV) - the Resistive Transmitter (Potentiometer) with the Converter PTK 1

4.5.1 EPV – the 2-wire version (Fig. 10)

The position transmitter with the converter PTK1 is in the plant adjusted to have the output current signal on the terminals 81-82 (the wiring diagram Z23) as follows:

in the position "open" 20 mA

in the position "closed"4 mA

If the transmitter requires a new adjustment follow these steps:

- Put the actuator to the position "closed" and switch the power supply off.
- Adjust the resistive transmitter according to the previous chapter. The resistance is to be metered on the terminals R-R (Fig. 10). The used transmitter resistance is 100 Ω .
- Switch the converter's power supply on.
- Turn the adjusting trimmer ZERO (Fig. 10) to adjust the output current signal rate measured on the terminals 81-82 to 4 mA.
- Set the actuator to the position "open".
- Turn the adjusting trimmer GAIN (Fig. 10) to adjust the output current signal rate measured on the terminals 81-82 to 20 mA.
- Check the output signal of the converter in the both limit positions, and repeat the procedure if needed.




Fig.10

Note:

The output signal of 4-20mA can be adjusted at the range from 75 up to 100% of the rated stroke stated on the actuator's nameplate. At values less than 75% the value 20 mA is reduced proportionally.

4.5.2 EPV – 3-wire version (Fig. 11)

The resistive transmitter with the converter is in the plant adjusted to have the output current signal metered on the terminals 81-82 (the wiring diagram Z257 - without power supply) as follows:

- in the position „open“ 20 mA or 5 mA, resp. 10 V
- in the position „closed“ 0 mA or 4 mA, resp. 0 V according to the specified version of the converter.

If the transmitter requires a new adjustment follow these steps:

- Put the actuator to the position „closed“ and switch the power supply off.
- Adjust the resistive transmitter according to the previous chapter. The resistance is to be metered on the terminals 0%-100% (Fig. 7). The used transmitter resistance is 2000W or 100 W.
- Switch the converter's power supply on. Turn the adjusting trimmer A (Fig. 7) to adjust the output current signal rate measured on the terminals 81-82.
- Set the actuator to the position „open“.
- Turn the adjusting trimmer B (Fig. 7) to adjust the output current signal rate measured on the terminals 81-82.
- Check the output signal of the converter in the both limit positions, and repeat the procedure if needed.

Note:

The output signal of (0-20mA, 4-20mA or 0-5mA, 0-10V - according to the specification) can be adjusted at the range from 85 up to 100% of the rated stroke stated on the actuator's nameplate. At values less than 85% the value of the output signal is reduced proportionally.

Note:

The output signal of 4-20mA can be adjusted at the range from 75 up to 100% of the rated stroke stated on the actuator's nameplate. At values less than 75% the value 20mA is reduced proportionally.




Fig.11

4.6 Adjustment of Capacitive Transmitter CPT1/A (Fig.12)

The chapter describes adjustment of the capacitive transmitter to the specified parameters (standard values of output signals) in case they are reset. The capacitive transmitter serves as a position transmitter of electric actuators with unified output signal of 4÷20 mA.

Note:

In case that reversed output signals are needed (in the position "OPEN" minimum output signal) contact personnel of service centres.

The capacitive transmitter CPT1/A is adjusted by the producer to the fixed operation angle according to the order and wired according to the wiring diagrams placed into the cover. Check the power supply of the user after connecting to terminal of the terminal board before the transmitter is electrically checked. Adjustment of the capacitive transmitter can be performed when the position switches are adjusted. The adjustment is performed with the power supply of 230 V/50 Hz and ambient temperature of $20 \pm 5^\circ\text{C}$.

The following versions of electric actuators with built capacitive transmitters can be specified:

- A) The version without any power supply (2-wire version)**
- B) The version with a power supply (2-wire version)**

A.) Adjustment of the Capacitive Transmitter without any Power Supply

Before connecting check the power supply. The measured voltage should be in range from **18 up to 28 V DC**.



The voltage of the power supply must not be in any case higher than 30 V DC. The transmitter can be irreversibly damaged!

While checking or adjusting the output signal of 4÷20 mA follow these steps:

- Connect a mA meter of precision class 0,5 and loading resistance lower than 500Ω serially with the transmitter (pole "-"; terminal 82)
- Put the actuator to the position "CLOSED", the signal value should decrease.
- Check the signal value for the position "CLOSED" (4 mA).
- Tune the signal with loosening the fixing screws (15) and turning the trimmer (10) until the required value of 4 mA is reached. Tighten the fixing screws.
- Put the actuator to the position "OPEN", the signal value should raise.
- Check the signal value for the position "OPEN" (20 mA).
- Tune the signal with turning the trimmer (20) until the required value of 20 mA is reached.
- Check the signal value for the position "CLOSED" and then for the position "OPEN".
- Repeat the procedure until the change from 4 to 20 mA is reached with deviation less then 0,5 %.
- Disconnect the meter and lock the screws with a varnish.




Fig.12

B.) Adjustment of the Capacitive Transmitter with the Power Supply

1.) Check the power supply: 230 V AC, resp. 24 V AC (according to version) $\pm 10\%$, on the terminals 1, resp. 60 and 61

2.) While checking or adjusting the output signal of 4÷20 mA follow these steps:

- Connect a mA meter of precision class 0,5 and loading resistance lower than 500Ω on the terminals 81, 82.
- Follow the procedure described in the previous chapter A.



The user has to arrange grounding of the 2-wire circuit of the capacitive transmitter to the electrical ground of a joined controller, computer, etc. The grounding should be performed only in one place in any part of the circuit outside the electric actuator!

Note:

The trimmer (20) can be used to adjust the output signal of the capacitive transmitter to any value of operation stroke in range from ca 40% up to 100% of the value of the operation stroke adjusted by the producer and stated on the actuators nameplate.


4.7 Adjustment of the DCPT3M transmitter

Before the transmitter **DCPT3M (Fig.13)** adjustment the position switches S3 and S4 have to be adjusted. Adjustment consists in setting of the output signal value in the limit positions of the actuator.

By default (unless determined otherwise by the customer), the manufacturer aligns the DCPT3M transmitter so that output signal value 4mA is set for the limit position "closed" and 20 mA for the position "opened". By default the characteristics of the output signal is set to 20-4 mA (ascending).

Notes 1: -this type of transmitter enables the assignment 4 mA / 20 mA of the output signal value to any limit position of the actuator.

2:-the transmitter is adjustable within the range of 35 to 100% of the full stroke specified in the nameplate. By wrong stroke adjusting (outside transmitter range), error appears (LED blinking 2-times)



4.7.1 Setting of limit positions

If limit positions require re-adjustment, proceed as follows:

Adjustment of the "4 mA" position:

- Turn on the power supply voltage to DCPT3M
- Reset the actuator to the limit position that you want to assign 4 mA signal value to and press (for about 2 seconds) the pushbutton "4", until LED flashes

Adjustment of the "20 mA" position:

- Turn on the power supply voltage to DCPT3M
- Reset the actuator to the limit position that you want to assign 20 mA signal value to and press (for about 2 seconds) the pushbutton "20", until LED flashes

Notes 1: Transmitter error code may result when the first limit position is saved (2x LED flash). The error code is erased by saving of the second limit position, provided that the saved limit positions are within 35 to 100% of the rated stroke specified in the nameplate.

If necessary, please change the characteristic of the output signal from descending to ascending or vice versa, according to the following chapter.

4.7.2 Setting of the ascending/descending characteristic of the output signal

When the characteristic of the transmitter output signal is changed, the set limit positions "4 mA" and "20 mA" are maintained, however the operating range (stroke of DCPT3M) between these two positions is changed to the complement of the original operating range.

When the DCPT2 transmitter is set so that output signal value 4mA is set for the limit position "closed" and 20 mA for the position "opened", the characteristic must be set to 20-4 mA (ascending) (Adjusted by producer if customer define others).

When the DCPT2 transmitter is set so that output signal value 20 mA is set for the limit position "closed" and 4 mA for the position "opened", the characteristic must be set to 4-20 mA (descending).

If you need to toggle the characteristic of the transmitter output signal 4-20 mA (ascending), or 20-4 mA (descending), please proceed as follows:

- Turn on the power supply voltage to DCPT3M
- For 4-20 mA (ascending characteristic) press the pushbutton "20" and subsequently "4" and hold both buttons pressed until LED flashes.
- For 20-4 mA (descending characteristic) press the pushbutton "4" and subsequently "20" and hold both buttons pressed until LED flashes.

4.7.3 Calibration MENU

- For current value increasing push and hold the button „20“ until current increase. Longer holding The calibration menu enables setting of default parameters and calibration of current values 4 and 20 mA (fine tuning of the value of the output current signals 4 and 20 mA in the limit positions).

Calibration mode input for adjusting of output current:

- Turn off the power supply to the transmitter power supply source.
- Press and hold the "4" and "20" adjustment pushbuttons.
- Turn on the power supply to the transmitter power supply source.
- Hold both pushbuttons until the first and on to the second flash of LED.
- In this menu input is firstly adjusted for value 4 mA.

Current 4-20 mA adjusting in calibration mode:

- For current value decreasing push and hold the button „4“ until current decrease. Longer holding of this button means autorepeat of current value. Releasing of this button means writing current value. of this button means autorepeat of current value. Releasing of this button means writing current value.

Toggling between 4 and 20 mA in the calibration mode:

- For 4 mA press the pushbutton "20" and subsequently "4" and hold both buttons pressed until LED flashes.
- For 20 mA press the pushbutton "4" and subsequently "20" and hold both buttons pressed until LED flashes.

Restoring factory (default) settings:

Warning: Using this all adjusted parameters will be canceled and adjusted to factory settings (current calibration, positions 4 and 20 mA). Therefore it is necessary to make new transmitter calibration.

- Turn off the power supply to the transmitter power supply source.
- Press and hold the "4" and "20" adjustment pushbuttons.
- Turn on the power supply to the transmitter power supply source.
- Hold both buttons until first and second LED blink.
- Turn-off and turn-on transmitter power supply again.
- LED stays lighting and after 10 sec. go out.

Leaving calibration mode:

- After 10 sec. not working in calibration mode, LED will go out as a signal of leaving calibration mode. If LED is blining, error appears.

Transmitter errors:

In case of error LED starts blinking. Number of LED blinking means number of error in table No. 4. After longer pause blinking process repeats. In case of more errors, number of errors are blinking one after another. Longer pause between blinking separate particular errors.

Example of error number 2 and 1 according to LED blinking:



| TABLE 4 | | |
|------------------------|--|---|
| Number of blinking LED | Error | Eliminate the error |
| 1x | Transmitter position outside operating range | - change the characteristics of the output signal, respectively. - return the actuator output member to the working area, resp. - sort the end positions of the transmitter |
| 2x | Incorrectly set working stroke | - check the stroke adjustment range and reset the transmitter stroke. |
| 3x | Sensor error | - change transmitter. |
| 4x | Incorrect parameters in EEPROM | - change transmitter. |

4.8 Electric local control (Fig.15)

-additional equipment

If necessary (accession, function check and so on), it is possible to preset EA by local electric control with secured power feeding. Upon switching the local control to "LOCAL" mode, it is possible to use OPEN and CLOSE buttons to control the movement of the output element in the entered direction. LEDs indicate individual modes of the local control.

The control is possible after removing the padlock (1). Control mode selection is changed by sequential pressing of the button (2) **REMOTE-OFF-LOCAL** to "Remote" "Shut off", "Local", "Shut off". Individual modes are cycled by sequential pressing. The selection is indicated by LEDs visible on the front panel of the local control.

LED**PWR** (6) indicates the presence of supply voltage to control the local control.

Individual local control modes:

The „**OFF**“ mode - this mode does not enable remote or local control of EA. The mode is indicated by LEDs **REMOTE** (7) and **LOCAL** (8) being off

The „**LOCAL**“ mode - this mode enables EA control in the open and close direction and to stop using buttons **OPEN** (3) (open), **CLOSE** (4) (close) and **STOP** (5). The „**LOCAL**“ mode is indicated by **LOCAL** (8) LED being lit. When **OPEN** button is pressed in this mode, it is indicated by **OPEN** LED being lit (9). When **CLOSE** button is pressed in this mode, it is indicated by **CLOSE** LED being lit (10). When **STOP** button is pushed, the signal LEDs **OPEN** (9) and **CLOSE** (10) are switched off.

The „**REMOTE**“ mode - in this mode the EA can be remotely controlled by commands from master system. The „**REMOTE**“ mode is indicated by **REMOTE** (7) LED being lit. In this mode the OPEN, STOP and CLOSE buttons are not functional.

After finishing the work with electrical local control, we recommend to return the padlock to button (2) in mode „**REMOTE**“ and lock out the device to avoid unwanted tampering by unauthorized person.




Fig. 15

5. Service and Maintenance

5.1 Service



1. In general it is supposed that the EA is serviced by a qualified person as required in the Chapter 1!
2. After the EA is put into operation it is necessary to check whether during manipulation its surface finishing was not damaged – the damages should be eliminated to prevent the surface against deterioration caused by corrosion!

- The EA **UM 2-Ex** requires just an insignificant service. The reliable operation is determined by the correct putting into operation.
- The service of the EA results from the operation conditions and generally consists in treating the information for subsequent performing of a required function. The EA can be controlled by remote control electrically or manually on the place of their installation. The manual control is available with a hand wheel.
- The service staff should arrange the required maintenance and prevent the actuator during operation against impacts of environment and climate what exceed the frame of allowed influences stated in the Chapter "Operation Conditions".
- It is necessary to avoid overheating of the EA surface, exceeding of parameters stated on the nameplate and abnormal vibrations of the EA.

Manual control:

- If the manual control is needed (adjustment, function checking, failures etc.) the staff can reset the regulated member using the handwheel. While rotating the handwheel clockwise the output element moves in the direction "CLOSING".

5.2 Maintenance - extent and periodicity

During inspections and maintenance is needed to tighten all screws and nuts that affect the tightness and coverage. Similarly, once a year should be checked and if necessary tighten mounting screws of the terminal wires and assuring of the slip-on joints with wires.

The interval between two preventive inspections is four years.

The replacement of cover gaskets and gasket of an oil filling is needed in case of damage or after 6 years of the operation.

The grease in the supplied actuators is designed for the lifetime of the product.

It is not necessary to change the grease during the operation of the actuator.

During inspection, replace the sealing O-ring (see Chapter 6) between the bottom and top cover - replace with original O-ring from manufacturer.

Lubrication:

- the gearbox and drive mechanism on the control board - grease:
 - in versions with temperatures -25°C till +55°C - grease μ HF 401/0, resp. GLEITMO585
 - in versions with temperatures -50°C till +40°C - grease ISOFLEX TOPAS AK 50
 - in versions for climate with temperatures -60°C till +40°C grease DISCOR R-EP 000.



Lubrication of the valve stem is independent on maintenance of the EA!

After every potential flooding of the product check, whether there is no water inside. After eventual water penetration, dry the product before repeated putting into operation and replace damaged sealings, resp. other parts of EA. identically check also tightness of cable bushings and replace them, if they are damaged.

- Every six months it is recommended to perform one check move in frame of adjusted operation stroke to verify reliability of functioning with setting back to the original position.
- If the audit rules do not determine else the inspection of EA is performed ones a year and tightening of all connecting and grounded screws have to be checked to avoid overheating.
- After 6 months from putting of EA into operation and once a year it is recommended to check tightening of fixing screws between the EA and the valve. (Tighten the screws with the cross system.)

- While connecting and disconnecting of the EA check the tightness of cable glands – those with damaged sealings should be replaced by new ones of the approved type!



Keep the EA clean and take care about removing impurities and dust. The cleaning has to be performed regularly according to the operation possibilities and requirements.


5.3 Maintenance to assure inexplosiveness

A hour before removing of the actuator cover it is needed to switch power supply off. The given period is required to assure cooling of the electric motor and the space heater below the admissible temperature value of the temperature class T5 (+100°C).

The fixing screws of the upper cover have to be always in full numbers, i.e. 4 pcs, with flexible washers and tightly fastened.

The actuators with damaged closing surfaces, e.g. scratches, rifts, etc. have to be immediately put out of operation.


- While connecting and disconnecting of the EA check the sealing rings of the cable leads – damaged and worn sealing should be replaced by original rings!
- Keep the EA clean and take care about removing impurities and dust. The cleaning has to be performed regularly according to the operation possibilities and requirements.
- Reparation of EA (basically the parts the resisting closures consist with, have substantial influence on safety) is allowed perform only by producer, witch according to certificated documentation and by performing of required tests (inclusive of static pressure test of resisting clouser parts guarantee the fulfill required standares and rules for this products.



The closing surfaces are:

Closure surfaces are:

1. Bottom enclosure and top enclosure
2. Bottom enclosure and crown wheel
3. Bottom enclosure and manual control case
4. Manual control case and manual control shaft
5. Moulded joint between the crown wheel and signaling disc
6. Threaded joint - bottom enclosure and stop screw
7. Threaded joint - bottom enclosure and cable glands.
8. Cemented cylindrical gap - Top enclosure and sight Ex
9. Bonded threaded surface M8 LH_6H/6g, L= 6mm, thread pitch 1.25, number of pitches 4.8, Loctite 243 - to prevent against loosening of the stop screw

Gap of flameproof enclosure of local control are between:

1. Bushing tube – rear enclosure of local control
2. Threaded joint – Bushing and bushing tube
3. Front enclosure and rear enclosure
4. Aperture and front enclosure.

Enclosure joint surfaces are designed according to the requirements of table 2 and 3, EN 60079-1,

To seal the gaps against entry of fluids and dust, O-rings are used from the outside except for the gap of flameproof enclosure.

**Caution:**

After disassembly and re-assembly of top enclosure and bottom enclosure (see gap of flameproof enclosure 1 in chapter 5.3) the sealing O-ring must be replaced according following table:

| O- Ringlet | Dimension | Standard | PNm | Material | Manufacturer |
|------------------------------------|-------------|------------------|------------|-----------|---------------|
| Bottom enclosure and top enclosure | 202,79x3,53 | AS 568B/B S 1806 | 62 732 156 | NBR N7T40 | |
| Local control | 105x3 | STN 02 9281.9 | 62 732 390 | MVQ | Rubena Náchod |

5.4 Troubleshooting

- In case of a mains failure the EA stands in the position where it was before the failure occurred. If needed the EA can be reset using the manual control (with the handwheel). When necessary EA can be manually operated (hand wheel), at doing this, pay attention to keep the movement of the EA output part within the range of the set stroke so as to avoid losing the adjustment of the limit position switches or position transmitter or regulator. After supply voltage recovery EA is prepared for operation.
- In case of a failure of a part of the EA the part can be replaced by a new one. The exchange is to be committed by the producer or a contracted service firm.
- In case of an EA failure, which cannot be eliminated directly in operation, follow instructions for under-guaranty and after-guaranty service.

Table 7

| Failure | Cause | Troubleshoot |
|--|--|--|
| There are no revolutions of motor rotor when operating the push-buttons. | 1. No voltage on the electric motor connectors. | Check connection and voltage presence. |
| | 2. No voltage on the control part. | Check connection of the control part. |
| The EA fails to stop at the limit positions. | 1. Incorrect setting-up of the switches. | Perform adjustment. |
| | 2. The microswitch is defective | Replace the microswitch for a new one and adjust. |
| | 3. Incorrect actuator connection | Check connection of position and torque switches in control circuit. |
| The EA stops at the mid-position. | There is an obstacle in the valve or part of it seizes. | Perform reversing of the EA, move it to the original direction and, in the case that the failure repeats, repair the armature. |
| There is no indication of reaching these positions in the final positions. | 1. The LEDs fail to operate. | Replace the LEDs for new ones. |
| | 2. Incorrect adjustment of the position signal switches. | Adjust the position signal switches. |
| | | In case that some EA failures still remain, contact the service centres. |

- *Note: If the EA has to be dismantled follow the procedure of the Chapter "Dismantling"*



The EA can be dismantled to be repair purpose by qualified and trainer persons only! The training can be preformed by the producer or by a contracted service firm.

6. Accessories and Spare Parts

As accessories the **handwheel** is packed with the product.

6.1 List of the Spare Parts

Table 8: Spare Parts


| Spare part | Order Nr. | Position | Figure |
|--|---------------------------|----------|--------|
| Electric motor; 100 W; 24 VAC; | 63 592 XXX | 2 | 1a |
| Electric motor 120 W/228VA; 120 V AC, 60 Hz; | 63 592 XXX | 2 | 1a |
| Electric motor; 120 W/228VA; 230V AC | 63 592 394 | 2 | 1a |
| Electric motor r; 180 W; 3x400V AC; 3x415 | 63 592 330 | 2 | 1a |
| Capacitor 8 μ F | Electric motor components | 2 | 1,1a |
| Microswitch CHERRY DB 6G-A1LB | 64 051 466 | 26,27 | 8 |
| | | - | 2,6 |
| Capacitive transmitter CPT 1 | 64 051 499 | 10 | 12 |
| Resistant wire transmitter (potentiometer) RP19; 1x100 | 64 051 812 | 5 | 9 |
| Resistant wire transmitter (potentiometer)RP19; 1x2000 | 64 051 827 | 5 | 9 |
| Resistant wire transmitter (potentiometer)RP19; 2x100 | 64 051 814 | 5 | 9 |
| Resistant wire transmitter (potentiometer)RP19; 2x2000 | 64 051 825 | 5 | 9 |
| Transmitter DCPT3M | 64 051 059 | - | 13 |
| Power supply DX3004.P24 | 64 051 184 | - | 1 |
| Ringlet 202,79x3,53 AS 568 B/BS 1806 (ULR 2PA-Ex) | 62 732 156 | - | - |
| Ringlet 105x3 MVQ (local control) | 62 732 390 | - | - |



he disassemble of EA for the purpose of repair is possible only for the manufacturer!

7. Enclosures

7.1 Wiring diagrams UM 2-Ex



Legend:

Z528a.....wiring diagram of 3-phase electric motor with thrust and position switch and with space heater and additional thrust relay (valid for UM 2-Ex)

B1.....resistive transmitter (potentiometer)
single
B2.....resistive transmitter (potentiometer)
double
B3.....capacitive transmitter
S1..... torque switch "open"
S2..... torque switch "closed"
S3..... position switch "open"
S4..... position switch "closed"
S5..... additional position switch "open"
S6..... additional position switch "closed"
ReS11relay of torque of switch S1
ReS12relay of torque of switch S2
M, MS.....electric motor

C..... capacitor
Y..... brake of electric motor (valid for UM 2-Ex)
E1..... space heater
K11,K12 coil of relay
KM1, KM2 .. reverse contactor (valid for UM 2-Ex)
F1 electric motor thermal protection
F2..... space heater thermal switch
X..... terminal board
XC connector (is not valid for these types EA)
I/U..... output current (voltage) signal
R_L loading resistor

Note 1: Thermal protection of single-phase electric motor (Z404) is standardly built-in in electric motor, on the neutral wire. In case of 3-phase EA, model UM 1-Ex thermal protection of the motor F1 is not led to the terminals 5 and 6 (thermal protection of electric motor is built-in). Thermal protection is led to the terminals 5 and 6 only at 3-phase electric motors of EA, model UM 2-Ex.

Note 2: In case of version UM 1-Ex, UM 2-Ex equipped with the double resistance transmitter, terminal connectors 30 and 34 of the additional position switches have not been taken out.


Note 3: Torque switching is fitted with mechanical interlocking device only for UM2-Ex.

Note 4: Jumpers 2-11, 3-15, 12-19 and 16-23 terminal board in wiring diagram Z528 and jumpers 12- 19 and 16-23 terminal board in wiring diagram Z528a and Z528b are standardly delivered from the producer.

7.2 Operation Logic Diagram of switches and relays

| Switch | Terminal Nr. | open | | closed | |
|--------------|--------------|------------------|--|--------|--|
| | | Operating stroke | | | |
| S1 | 11 (M2) - 12 | | | | |
| | 12 - 14* | | | | |
| S2 | 15 (M3) - 16 | | | | |
| | 16 - 18* | | | | |
| S3 | 19 - 20 | | | | |
| | 20 - 22 | | | | |
| S4 | 23 - 24 | | | | |
| | 24 - 26 | | | | |
| S5 | 27 - 28 | | | | |
| | 28 - 30 | | | | |
| S6 | 31 - 32 | | | | |
| | 32 - 34 | | | | |
| ReS11 | 35 - 36 | | | | |
| | 36 - 38 | | | | |
| ReS12 | 39 - 40 | | | | |
| | 40 - 42 | | | | |

 Contact connected


 Contact disconnected

Note 1: For wiring diagram Z528, Z528a and Z528b contacts 14 and 18 are not terminated.


Note 2: Relay ReS11 switches simultaneously with switch S1 and relay ReS12 switches simultaneously with switch S2.

7.3 Dimensional drawings


Explosion-proof electric multi-turn actuators Unimact **UM 1-Ex** – flange connection ISO 5210



Explosion-proof electric multi-turn actuators Unimact **UM 1-Ex** – flange connection DIN 3338





Explosion-proof electric multi-turn actuators Unimact **UM 1-Ex** – flange connection OST 26-07-763 typ M



Explosion-proof electric multi-turn actuators Unimact **UM 2-Ex** flange connection ISO 5210

P-1483

ISO 5210 - F07 - N - ...
 ISO 5210 - F10 - N - ...



7.4 Guarantee service check report

| | |
|------------------------------|------------------------------------|
| Service center: | |
| Date of repair: | Guarantee repair no.: |
| User of actuator: | Claim applied by: |
| Actuator type number: | Actuator production number: |
| Product claim fault: | Detected product fault: |
| Used spare parts: | |
| Remarks: | |
| Issued on a day: | Signature: |

7.5 Post guarantee service check report

| | |
|--------------------------------|------------------------------------|
| Service center: | |
| Date of repair: | |
| User of actuator: | Actuator operating place : |
| Actuator type number: | Actuator production number: |
| Detected product fault: | |
| Used spare parts: | |
| Remarks: | |
| Issued on a day: | Signature: |

7.6 Commercial representation

Slovak Republic:

Regada, s.r.o.,
Strojnícka 7,
080 01 Prešov
Tel.: +421 (0)51 7480 460,
Fax: +421 (0)51 7732 096,
E-mail: regada@regada.sk