



CE

# ***INSTALLATION, SERVICE AND MAINTENANCE INSTRUCTIONS***



***Electric linear thrust actuator ST 2, STR 2***

## TEST CERTIFICATE

ELECTRIC LINEAR THRUST ACTUATOR ST 2, STR 2	
Type number 492.....	Power supply ..... V ..... Hz
Serial number .....	Set switching-off thrust ..... N
Production year .....	Operating speed ..... mm/min
Wiring diagram .....	Stroke ..... mm
.....	Input operating signal .....
Warranty period ..... months	Transmitter (potentiometer) .....
Serial number of electric motor .....	
Serial number of transmitter .....	
Serial number of position controller .....	
Tests made in accordance with TP 74 0814 00	
Tests made by .....	
Date .....	Signature and stamp .....

## COMPLETENESS CERTIFICATE

Used valve .....	
Assembled by: Firm .....	
Name.....	
Warranty period ..... months	
Date .....	Signature and stamp.....

## INSTALLATION CERTIFICATE

Location .....	
Installed by: Firm .....	
Name .....	
Warranty period..... months	
Date .....	Signature and stamp.....

*Please read these instructions carefully before mounting and operating the actuator!*

*Preventive and safety-measures applied on the actuator can not offer required safety level till the actuator and its safety systems are not applied by required and described way and if installation and maintenance is not applied according to applicable instructions and rules!*

## **Contents**

1. General data .....	2
1.1 Purpose and applications.....	2
1.2 Safety instructions.....	2
1.2.1 Characteristics of the Product Regarding Its Exposure Rate.....	2
1.2.2 Product influence to environment .....	2
1.3 Instructions for stuff training .....	2
1.4 Warning for safety use .....	3
1.5 Data specified on electric actuator .....	3
1.6 Warranty conditions .....	3
1.7 Under-guarantee and after-guarantee service .....	4
1.7.1 Lifetime of actuators .....	4
1.8 Operation conditions .....	4
1.8.1 Product location and operation position.....	4
1.8.2 Operation Environment.....	5
1.8.3 Power supply and duty cycle.....	6
1.9 Conservation, packing, transport, storing and unpacking .....	6
1.10 Appreciation of the product and packing .....	7
2. Description, function and specifications .....	7
2.1 Description and function .....	7
2.2 Basic specifications.....	8
3. Installation and dismantling of actuator .....	12
3.1 Installation.....	12
3.1.1 Mechanical connection.....	12
3.1.2 Electric connection and checking of function.....	14
3.2 Dismantling .....	15
4. Adjusting of actuator .....	15
4.1 Gear unit adjustment.....	16
4.2 Adjustment of position-indicating unit (Fig.5) .....	16
4.3 Adjustment of resistant transmitter (Fig. 6) .....	16
4.4 Adjustment of the Electronic Position Transmitter (EPV) - the Resistive Transmitter (Potentiometer) with the Converter PTK 1 .....	17
4.4.1 EPV – the 2-wire version (Fig. 7,7a).....	17
4.4.2 EPV – 3-wire version (Fig. 8,8a).....	18
4.5 Adjustment of the Capacitive Transmitter CPT1/A (Fig.9) .....	19
4.6 Adjustment of position controller .....	20
4.6.1 Setting of controller .....	20
4.6.2 Watching operation and error states .....	21
5. Service, maintenance and troubleshooting .....	22
5.1 Service.....	22
5.2 Maintenance - extent and periodicity .....	23
5.3 Troubleshooting .....	24
6. Accessories and spare parts .....	25
6.1 Accesories .....	25
6.2 Spare parts list.....	25
7. Enclosures .....	26
7.1 Wiring diagrams .....	26
7.2 Dimensional drawings.....	36
7.3 Guarantee service check report.....	42
7.4 Post guarantee service check report.....	43
7.5 Commercial representation.....	44

The Installation, Service and Maintenance Instructions are drawn up according to requirements of EC Executive Nr. 2006/42/EC "Uniform requirements for machines and devices from the point of view of safety and health care", to save life and health of users and to avoid material damages and exposure environment to danger.

## 1. General data

### 1.1 Purpose and applications

Electric linear thrust actuators (hereinafter **EA**) of **ST 2** or **STR 2** types with constant speed are high-powered electric-mechanical products, designed for direct installations onto controlled devices (regulating bodies -valves, etc.). EA of ST 2 types are provided for remote control of closing bodies, and EA of STR 2 types for automotive control of regulating bodies in both directions of their movement. They can be equipped with means of measuring and control of technological processes where an unified analogue direct current or voltage signal is an information bearer on their input and/or output. They can be used in heating, energy, gas, air-conditioning and other technological systems, which they are suitable for, regarding their features. They are connected with controlled devices with a flange according to ISO 5210 or using a pillars and flanges.



1. **Do not count with tight closing performed by control signals of EA STR 2.**
2. **It is forbidden to use EA as a lifting mechanism!**
3. **Switching of actuator by a semiconductor switches have to be consulted with producer.**

### 1.2 Safety instructions

#### 1.2.1 Characteristics of the Product Regarding Its Exposure Rate



EA of **ST 2** and **STR 2** types are reserved technical devices with higher rate of danger, with possibility of installation in areas specially danger regarding casualties caused by electric current. Electric actuators are according to directive LVD 2014/35/EU and standard EN 61010-1+A1 in the edition in terms of valid certificate, assigned for installation category II (overvoltage category), pollution degree 2.

#### 1.2.2 Product influence to environment

**Electromagnetic compatibility (EMC):** the product complies with the requirements of the Directive 2014/30/EU of the European Parliament and of the Council on the approximation of the laws the Member States relating to the electromagnetic compatibility and with the requirements of standards as well EN IEC 61000-6-4, EN IEC 61000-6-2, EN IEC 61000-3-2+A1 and EN 61000-3-3+A1+A2, in the edition in terms of valid certificate.

**Vibrations caused by the product:** product influence is negligible.

**Noise produced by the product:** The maximum allowable noise level (A) of the product measured in a place of operation is 80 dB (A).

### 1.3 Instructions for stuff training

**Requirements for professional qualification of people performing installation, service and maintenance**



The electrical connection of the actuator can only be carried out by a person in accordance with legislative requirements of the given country, depending on the required areas of location/use. Service can be performed only by workers professionally qualified and trained by the producer or contracted service centre.

### 1.4 Warning for safety use



1. Products are assigned for operation in environment consist of gas, steam and vapours, with temperature range:  $-25^{\circ}\text{C}$  to  $+55^{\circ}\text{C}$  or  $-50^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$  or  $-60^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$ , with pressure range from 0.8 to 1.1 bar.
2. If the actuator is placed on device which regulate medium with higher temperature than  $+55^{\circ}\text{C}$ , protect the actuator by additional construction in order to maintain ambient temperature max.  $+55^{\circ}\text{C}$  and also to stop temperature transmitting through junction component!
3. Cable glands blinds are assigned only for transport and storage period, i.e. for period till the actuator is builded into operation, than blinds must be replace by connecting cable.
4. In case of not using one of the cable gland, it has to be replaced with a suitable blinding plug.
5. Temperature at the point where the cables enter the actuator can reach max.  $90^{\circ}\text{C}$ . When choosing the connection cables for the actuator, it is therefore necessary to consider this temperature as well.

#### Product protection

Actuator does not have its own protection against a short-circuit therefore feeding voltage supply must include a breaker or a fuse which is also used as a master switch. For protection, we recommend to use a fuse type "T" or a contactor type "C".

**Type of equipment from a connection point of view:** The equipment is designed for permanent connection.

### 1.5 Data specified on electric actuator

Nameplate:

Warning plate:

⊕	<b>REGADA</b>	TYP	№	
		kN	mm.min <sup>-1</sup>	IP ⊕
CE	Made in Slovakia	mm	V	A



Nameplate contains the basic data concerning identification, performance and electricity: indication of producer, type, serial number, max. load thrust and switching-off thrust, protection code, operating speed, supply voltage and current.

#### Graphic symbols on electric actuator

The graphic symbols used on electric actuator substitute the text messages. Some of them are in accordance with EN ISO 7010, ISO 7000 and IEC 60417 within valid edition.



Dangerous voltage

(EN ISO 7010-W012)



Stroke of the electric linear actuator



Switching-off thrust



Manual control

(0096 ISO 7000)



Protection terminal

(5019 IEC 60417)

### 1.6 Warranty conditions

The supplier is responsible for completeness of the delivery and guarantees these specifications of the product which are stated in Technical conditions (TP) or specifications agreed in the Contract.

The supplier is not responsible for any deterioration of parameters caused by the customer during storage, unauthorised installation or improper operation.

## 1.7 Under-guarantee and after-guarantee service

Our customers are provided with professional service of our firm in installation, operation, service, maintenance, revision and help in troubleshooting for all our products.

Trained professionals wait for you also in our contracted service centres.

Under-guarantee service is performed by the service department of the production plant, or by a contracted service centre according to a written claim.

In case of occurring of any fault please let us know it and state:

- type code
- serial number
- ambient parameters (temperature, humidity...)
- duty cycle including frequency of switching
- type of switching-off (position or thrust)
- set switching-off thrust
- type of fault - description of claimed fault
- it is recommended to place also Installation certificate.

It is recommended to have **after-guarantee service** performed by the service department of the production plant, or by a contracted service centre.

### 1.7.1 Lifetime of actuators

The lifetime of an electric actuator (EA) is at least 6 years.

EA used for closing mode (closing valves) comply with the requirements for at least **15,000 working cycles** (cycle C – O – C: for linear EA).

EA used for regulating/modulating operation (control valves) comply with the below stated numbers of **operating hours** at the total number of 1 million start-ups:

Switching frequency				
max. 1,200 [h <sup>-1</sup> ]	1,000 [h <sup>-1</sup> ]	500 [h <sup>-1</sup> ]	250 [h <sup>-1</sup> ]	125 [h <sup>-1</sup> ]
Minimal lifetime expectancy – number of operating hours				
850	1,000	2,000	4,000	8,000

Time of **net operation** is min. 200 hours, max. 2,000 hours.

**Lifetime at operating hours** depends on loading and switching frequency.

*Note:* High switching frequency does not ensure better regulation. Setting of regulation parameters should be therefore made with the inevitably necessary switching frequency needed for the process in question.

## 1.8 Operation conditions

### 1.8.1 Product location and operation position

Electric actuators may be installed and operated in enclosed locations of industrial facilities with no temperature and moisture regulation, protected from direct climatic effects (such as direct sunlight). Moreover, special “marine” versions may be used in waste water treatment applications, water management, selected chemical applications, tropical environments and coastal areas.

Installation and operation of EA is possible in **any position**. Vertical position of output part axis and with the control part above the valve is usual.



**Warning:**

When the EA is installed in open air, **it must be** sheltered lightly to protect is against direct effects of atmosphere.

When installed in the areas with relative humidity more than 80%, in open air under a shelter is needed to connect the space heater directly – without a thermal switch.

## 1.8.2 Operation Environment

According to valid standard IEC 60 721-2-1, there are delivered these versions of electric actuators:

- 1) Version „**standard**“ for type climate temperate
- 2) Version „**tropical wet**“ for type climate tropical wet
- 3) Version „**cold**“ - for type climate cold
- 4) Version „**tropical dry and dry**“ for type climate tropical dry and dry
- 5) Version „**marine**“ for type climate marine
- 6) Version „**arctic**“ for type climate arctic.

In accordance with IEC 60 364-1, IEC 60 364-5-51 within valid edition the EA have to resist external effects and operate reliably:

In the conditions of the following types of environment:

- warm mild to very hot dry with temperature in range -25°C to +55°C ..... **AA 7\***
- cold to warm mild and dry with temperatures in range -50°C to +40°C ..... **AA 8\***
- cold to mild hot dry with temperatures in range -60°C až +40°C ..... **AA 1\*+AA 5\***
- with relative humidity 10 to 100 %, including the condensation of up to 0,029 kg water content per 1 kg of dry air, at above stated temperature..... **AB 7\***
- with relative humidity of 15÷100%, including the condensation of up to 0,036 kg water content per 1 kg of dry air, at above stated temperature..... **AB 8\***
- with relative humidity 5 to 100 %, including the condensation of up to 0,025 kg water content per 1 kg of dry, at above stated temperature ..... **AB 1\*+AB 5\***
- with height above sea level 2 000 m, with barometric pressure range 86 to 108 kPa ..... **AC 1\***
- with spraying or jet water from all directions—(protection enclosure IP x5) ..... **AD 5\***
- with shallow dive – (product in protection IP x 7) ..... **AD 7\***
- with submersion – (product with enclosure IPx8)..... **AD 8\***
- with strong dustiness – with a possibility of influences of inflammable, non-conducted and non-explosive dust; the middle layer of dust; the dust drop more than 350 but not more than 1000 mg/m<sup>2</sup> per day (products with protection enclosure of IP 6x) ..... **AE 6\***
- with atmospheric occurrence of corrosive and pollution media (with high degree of atmosphere corrosive aggressiveness); important presence of corrosive pollution ..... **AF 2\***
- with permanent exposure of big amount of corroding or contaminated chemicals and salt fog in execution for sea environment , for sewage water disposal plant and some chemical plant ..... **AF 4\***
- with a possibility of influences of mechanical stress:
  - medium sinusoid vibrations with frequency in range 10 up to 150 Hz, with shift amplitude of 0,075 mm for  $f < f_p$  and acceleration amplitude 9,8 m/s<sup>2</sup> for  $f > f_p$  (transition frequency  $f_p$  is from 57 up to 62 Hz) ..... **AH 2\***
  - medium sinusoid vibrations with frequency in range 10 up to 150 Hz, with shift amplitude of 0,15 mm for  $f < f_p$  and acceleration amplitude 19,6 m/s<sup>2</sup> for  $f > f_p$  (transition frequency  $f_p$  is from 57 up to 62 Hz) - applies to four-pillars version ..... **AH 2\***
  - medium impacts, shocks and vibrations ..... **AG 2\***
- with serious danger of plants and moulds growing ..... **AK 2\***
- with serious danger of animals occurrence (insects, birds, small animals) ..... **AL 2\***
- with detrimental influence of radiation:
  - of stray current with intensity of magnetic field (direct and alternating of power supply frequency) to 400 A.m<sup>-1</sup> ..... **AM 2-2\***
  - of sun radiation with intensity  $> 500$  a  $\leq 700$  W/m<sup>2</sup> ..... **AN 2\***
- with effects of medium seismic activity with acceleration  $> 300$  Gal  $\leq 600$  Gal ..... **AP 3\***
- with indirect danger of storm activity ..... **AQ 2\***
- with fast moving of air and strong winds ..... **AR 3 , AS 3\***
- with persons frequent touching earth potential (persons often touch conductive parts or they stand on the conductive basement) ..... **BC 3\***
- without any danger media with object ..... **BE 1\***

\* Marking in accordance with IEC 60364-1, IEC 60 364-5-51 within valid edition

### 1.8.3 Power supply and duty cycle

#### Power supply:

electric motor.....	230/220 V AC $\pm 10\%$ , 3x400/3x380 V AC, or 24 V AC/DC
control .....	230 V AC $\pm 10\%$ , or 24 V AC/DC $\pm 10\%$
potentiometer transmitter .....	$\sqrt{P \times R}$ V DC/AC
electronic positional transmitter (EPV) without power supply .....	15 up to 30 V DC, or 24 V DC
capacitive transmitter without power supply .....	18 up to 28 V DC
power supply frequency.....	50 Hz, or 60** Hz $\pm 2\%$

\*\* Note: At frequency of 60 Hz operating speed is increased by 1.2 times.

**Duty cycle** - according to EN (IEC) 60034-1 within valid edition:

**ES ST 2** are designed for **remote control**:

- short-time operation S2-10 min
- intermitted operation S4-25%, 6 up to 90 cycles per hour

**ES STR 2 with controller** are designed for **automatic regulation**:

- intermitted operation S4-25%, 90 up to 1200 cycles per hour

Note:

1. Duty cycle consist of load type, load factor and switching rate.
2. EA ST 2 is possible connect with an external controller and use this EA as controlled EA, for this EA stands duty cycle and power parameters as for type STR 2 with built-in controller. For EA with controller we do not suggest operating speed 60, 80, 100 and 120 mm per min.

### 1.9 Conservation, packing, transport, storing and unpacking

Surfaces without surface treatment are treated by conservation preparation MOGUL LV 2-3 before packaging .

Conditions of storing:

- Storage temperature: -10 to +50 °C
- Relative air humidity max.80 %
- Electric actuators and their accessories must be stored in dry, well ventilated covered spaces, protected against impurities, dust, soil humidity (by placement to racks, or on pallets), chemicals and foreign interventions
- There shall be no corrosive gases present in the storage areas.

The **EA ST(R) 2** are delivered in solid packages guaranteeing resistance in accordance with EN 60654 (IEC 60 654-1 and IEC 60 654-3).

Package is a box. Products in boxes is possible to load on the pallets (pallet is returnable). On the outer side of the package is stated:

- manufacturer label,
- name and type of product,
- number of pieces,
- other data – notices and stickers.

The forwarder is obliged to secure packed products, loaded on transportation means, against self-motion; if open transportation means are used, to secure their protection against atmospheric precipitations and splashing water. Displacement and securing of products in transportation means must provide their stable position, exclude the possibility of their inter-collision and their collision with the vehicle walls

They can be transported in unheated and not airtight areas of transport means with effects in range:

temperature: -25°C up to +70°C

humidity: 5 up to 100%, with maximal content of water 0.029 kg/kg per kg of dry air

barometric pressure: 86kPa up to 108kPa

**After receiving EA check whether during transport or storage the actuator was not damaged. Compare also whether the parameters on their nameplates are in accordance with accompanying documentation or the Contract. If any discrepancy or fault occur inform immediately your supplier.**



*If the actuators and accessories are not immediately installed, they have to be stored in dry, well-ventilated sheltered rooms, protected against dirt, dust, soil humidity (with placing onto shelves or onto pallets), chemical impacts and encroachment, at ambient temperature from -10°C up to +50 °C and relative humidity max. 80 %.*

***It is not allowed to store EA in the open air or in areas not protected against direct impact of climate!***

*If any scratch on the surface finishing occurs remove it immediately - you protect this way actuators against damaging with corrosion.*

If storing takes longer than 1 year, it is necessary to inspect lubrication fillings before putting EA into operation.

Assembled EA, but not put into operation is necessary to protect by the equivalent method as during storage (for example suitable protective cover).

After assembly to the armature in free and wet areas, or in areas with temperature changes, connect without delay heating resistor – thus preventing damages caused by corrosion from liquefied water in the control area.

Excessive preserving grease remove just operation.before putting EA into.

### 1.10 Appreciation of the product and packing

The product and its package are made of recycling materials. Do not throw the single parts of the package and of the product after their life but sort them according to instructions in corresponding executives or regulations of environment protection, and allow their recycling.

The product and its packing are not a source of any environment pollution or contamination and do not contain any dangerous waste.

## 2. Description, function and specifications

### 2.1 Description and function

The **ST 2** electric actuators consist of three parts differing in their function.

The **gear part** is made up by a linear adapter with pillars, or pillars with a flange with a connecting part for connection onto a controlled device, and gears placed in the bottom; on the other side drive mechanisms for control part units are surfaced.

The **control part (Fig. 4)** is placed on a control board (2) consisting of:

- an electric motor (7) (at single-phase version with capacitor)
- a thrust unit (controlled with a worm axial shift)
- a position-signalling unit (3) with a position transmitter (5)- positioner (resistive - potentiometer, capacitive or an electronic position transmitter) and with a mechanical local position indicator
- a space heater with a thermal switch (8)
- electric connection is realised using **terminal boards** (6) (located in the control area) and cable bushings (12), or **connector** with cable bushings

The **STR 2** version is equipped with an **electronic controller**. The electronic controller allows automatic output unit position adjustment in dependency on input signal value and provides additional functions.

#### **Additional accessories:**

**Manual control:** made up by a hand wheel with a worm gearing.

**Local electric control module (Fig.11).**

The **STR** version is equipped with an **electronic controller**. The position controller allows automatic position adjustment of the EA output part depending upon the input signal value and provides also additional functions.

## 2.2 Basic specifications

### Basic EA specifications:

switching-off thrust [N], operating speed [mm/min], operating stroke [mm], max. load thrust (valid for STR 2 with controller) [N] and electric motor parameters are given in Table 1.

**Table 1: Basic specifications**

Type number	Operating speed <sup>4)</sup>	Operating stroke	Max. load thrust <sup>2)</sup>	Switching-off thrust ± 10 [%]	Weight	Electric motor <sup>3)</sup>																	
						Power supply nominal voltage		Nominal			Capacitor capacity												
								power	speed	current													
	[mm/min]	[mm]	[N]	[N]	[kg]		[V] ±10%	[W]	[1/min]	[A]	[µF/V]												
1	2	3	4	5	6	7	8	9	10	11	12												
ST 2, STR 2, type number 492	10	8; 10; 12,5; 16; 20; 25; 32; 40; 50; 64; 80	21 500	19 000 – 25 000	17 - 21 kg (ST 2); 17,5 – 21,5 kg (STR 2)	Single-phase	230/220 AC	20	1 350	0,43	7/400												
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	20;32;40		21 500	19 000 – 25 000				60	2770	0,66													
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	50 <sup>1)</sup>		17 000	15 000 – 20 000								Single-phase/ direct current	24 AC/DC	93	3100	6,2/5	-						
			14 000	12 000 – 16 000																			
			17 000	15 000 – 20 000																			
	60 <sup>1)</sup>		14 000	12 000 – 16 000														Three-phase	3x400/3x380 AC	90	2 740	0,33	—
			14 000	12 000 – 16 000																			
			17 000	15 000 – 20 000																			
	80 <sup>1)</sup>		14 000	12 000 – 16 000		21 500	19 000 - 25 000																
			14 000	12 000 – 16 000																			
			14 000	12 000 – 16 000																			
	20;32;40		21 500	19 000 – 25 000				21 500	19 000 – 25 000														
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	20;32;40		21 500	19 000 – 25 000						17 000	15 000 – 20 000												
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	50 <sup>1)</sup>		21 500	19 000 – 25 000								14 000	12 000 – 16 000										
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	60 <sup>1)</sup>		21 500	19 000 – 25 000		17 000	15 000 – 20 000																
			17 000	15 000 – 20 000																			
			14 000	12 000 – 16 000																			
	80 <sup>1)</sup> 100 <sup>1)</sup>		17 000	15 000 – 20 000				14 000	12 000 – 16 000														
			14 000	12 000 – 16 000																			
			10 500	9 000 – 12 500																			
120 <sup>1)</sup>	10 500	9 000 – 12 500																					

1) For EA with regulator we do not suggest operating speed 50, 60, 80, 100 and 120 mm per min.

2) For duty cycle S4-25%, 90-1200 cycles per hour is max. load torque equal to max. load torque multiplied by 0,8 for remote control.

3) Switching elements for different type of load (also for EA) defines standard EN 60 947-4-1.

4) Anomaly of operating speed: -15% at temperatures under -10°C

± 10% at 230 V (or 3x400 V) AC

-50 up to +30% in dependence on load at 24 V AC/DC.

### Additional technical data:

**EA protection enclosure:** ..... IP 65, IP 67, IP 68 ((EN (IEC) 60 529 within valid edition))

According to definition for EA, enclosure IP68 fulfills following requirements:

-water column max. 10m

-time of continuous submersion in water max. 96 hours.

### Mechanical ruggedness:

sinusoidal vibrations ..... see part 1.8.2

drop resistance: ..... 300 drops with acceleration 5 m.s-2

seismic resistance:.....amplitude of the shock off 6 on Richter scale

**Self-locking:** .....guaranteed in range from 0 % up to 100% of max. load thrust  
**Electric motor protection:** .....with thermal switch  
**Output part backlash:** ..... max. 0,5 mm at load of 5% of maximum thrust  
**Switching-off**

Voltage ..... max. 250 V; 50/60 Hz; 2 A; or 250 V DC; 0,1 A; or 24 V DC; 2 A  
Hysteresis of position switches..... max. 3%  
Switching-off thrust is adjusted to maximum value with tolerance  $\pm 10\%$  if not agreed else.  
Operation stroke is adjusted at producer according to specified value.

### Space heater (E1)

Space heater - supply voltage: ..... corresponding with motor supply voltage (max. 250 V AC)  
Space heater power output:..... max. 25 W / 70 °C

### Thermal switch of space heater (F2)

Supply voltage: ..... corresponding with motor supply voltage (max. 250V AC)  
Switching-off temperature: .....  $+30^{\circ}\text{C} \pm 3\text{K}$   
Switching-on temperature: .....  $+20^{\circ}\text{C} \pm 4\text{K}$

### Position transmitters

#### Resistive position transmitter

Resistance (single **B1**) ..... 100; 2 000  $\Omega$   
Resistance (double **B2**) ..... 2 x 100; 2 x 2 000  $\Omega$   
Operating life of transmitter .....  $1.10^6$  cycles  
Load capacity ..... 0,5 W do  $40^{\circ}\text{C}$ , (0 W/ $125^{\circ}\text{C}$ )  
Maximum current of sliding contact ..... max.35 mA  
Maximum supply voltage..... $\sqrt{P \times R}$  V DC/AC  
Potentiometer linearity error .....  $\pm 2,5 [\%]^{1)}$   
Potentiometer hysteresis ..... max. 2,5  $[\%]^{1)}$   
Potentiometer values at limit positions:  
for **ST 2**: "O" (open).....  $\geq 93\%$ , "Z" (closed).....  $\leq 5\%$   
for **STR 2 with controller**: "O" (open).....  $\geq 85\%$  and  $\leq 95\%$ , "Z" (closed).....  $\geq 3\%$  and  $\leq 7\%$

#### Capacitive (B3): non-contact, life $10^8$ cycles

**2-wire connection** with power supply or without power supply

The current signal **4 ÷ 20 mA** (DC) is acquired from the capacitive transmitter supplied from the internal or an external voltage supply source. The electronics of the transmitter is protected against eventual wrong polarity and current overloading. The entire transmitter is galvanic insulated so several transmitters can be connected to one external voltage source.

Power supply voltage (with power supply) .....24 V DC  
Power supply voltage (without power supply) .....18 to 28 V DC  
Ripple voltage ..... max. 5%  
Max power input..... 0,6 W  
Load resistance.....0 to 500  $\Omega$   
Load resistance can be single side grounded.  
Influence of resistance on output current ..... 0,02%/100  $\Omega$   
Influence of voltage on output current ..... 0,02%/1V  
Temperature dependency..... 0.5% / 10 °C  
Output signal values at limit positions:

"O" .... 20 mA (terminals 81; 82)

"Z" .... 4 mA (terminals 81; 82)

Values tolerance of output signal of capacitive transmitter

"Z" .....  $\pm 0,2$  mA

"O" .....  $\pm 0,1$  mA

capacitive transmitter linearity error .....  $\pm 2[\%]^{1)}$   
capacitive transmitter hysteresis ..... max. 1  $[\%]^{1)}$

#### Electronic positional transmitter (EPV) - converter R/I (B3)

**a) 2-wire version** - without built-in power supply, or with built-in power supply

Current signal..... 4 ÷ 20 mA (DC)  
Power supply voltage (at version without build-in power supply).....15 to 30 V DC  
Power supply voltage (at version with build-in power supply) ..... 24 V DC  $\pm 1,5\%$

Load resistance (at version without build-in power supply)..... max.  $R_L = (U_n - 9V) / 0,02A$  [ $\Omega$ ]  
 (U<sub>n</sub> - power supply voltage [V])  
 Load resistance (at version with build-in power supply)..... max.  $R_L = 750 \Omega$   
 Temperature dependency..... max. 0,020 mA / 10 °C  
 Output signal values at limit positions:

"O" ..... 20 mA (terminals 81; 82)  
 "Z" ..... 4 mA (terminals 81; 82)

Values tolerance of output signal of EPV

"Z" ..... +0,2 mA  
 "O" .....  $\pm 0,1$  mA

#### b) 3-wire version - without built-in power supply, or with built-in power supply

Current signal..... 0 ÷ 20 mA (DC)  
 Current signal..... 4 ÷ 20 mA (DC)  
 Current signal..... 0 ÷ 5 mA (DC)  
 Power supply voltage (at version without built-in power supply)..... 24 V DC  $\pm 1,5\%$   
 Load resistance..... max. 3 k $\Omega$   
 Temperature dependency..... max. 0,020 mA / 10 °C  
 Output signal values at limit positions:

"O" ..... 20 mA, or 5 mA (terminals 81; 82)  
 "Z" ..... 0 mA, or 4 mA (terminals 81; 82)

Values tolerance of output signal of EPV and capacitive transmitter

"Z" ..... +0,2 mA  
 "O" .....  $\pm 0,1$  mA

EPV linearity error .....  $\pm 2,5[\%]$ <sup>1)</sup>  
 EPV hysteresis ..... max. 2,5 [%]<sup>1)</sup>

*1) from rated value of transmitter referred to output values*

Speed controller PWM:

- input control signal of speed ..... 4-20mA  
 - input resistor of input control signal ..... 500  $\pm 10\%$   
 - adjustment range of EA output speed between..... 20% to 100%

### Electronic position controller (N)

#### Controller software equipment:

##### A) Function and parameters

programmable **functions**:

- ..with functional buttons SW1, SW2 and LED diodes D3, D4 directly placed on controller
- ..with computer or terminal equipped with corresponding programme, using RS 232 interface.

programmable **parameters**:

- ..control signal
- ..response to SYS-TEST signal
- ..mirroring (ascending/descending characteristics)
- ..insensitiveness
- ..EA limit positions (only with computer and ZP2 programme)
- ..way of regulation

##### B) Operation states of controller

**Error message** from error memory: (using LED diodes and RS 232 and personal computer)

- ..control signal missing or faulty
- .. input value of current control signal under 3.5 mA
- ..existence of SYS-TEST signal
- ..activity of switches
- ..failure of feedback position transmitter

**Statistic data**: (using RS 232 and personal computer)

- ..number of controller operation hours
- ..frequency of relay switching in direction "opening"

- ...frequency of relay switching in direction "closing"

**Supply voltage:** ..... terminal 61 (L1) -1(N).....230 V AC,  $\pm 10\%$

**Frequency:** .....50/60 Hz  $\pm 2\%$

**Input control signals - analogue:** .....0 - 20 mA

.....4 - 20 mA

.....0 - 10 V

Input resistance for signal 0/4 - 20 mA ..... 250 $\Omega$

Input resistance for signal 0/2 - 10 V ..... 50k $\Omega$

(Actuator opens at rising of control signal.)

**Controller linearity:** ..... 0.5 %

**Controller insensitiveness:** ..... 1 - 10% (adjustable)

**Feedback (position transmitter):** ..... resistive 100 up to 10,000  $\Omega$   
current 4 up to 20 mA

**Power outputs:** .....2x relay 5 A/250 V AC

**Digital outputs:** .....4x LED (supply, error, adjustment, "opening", "closing" - with two-colour LED)

**Error status:** ..... control switch 24 V, 2W - POR

**Reaction at error situation:** .....transmitter error - error message LED

**Control signal missing:** ..... error message LED

**SYS mode:** ..... error message LED

**Adjusters:** ..... communication connector

..... 2x calibrating and adjusting button

**Manual control:** with hand wheel; rotating clockwise (counterclockwise) EA output part is moving in direction "Z" - closed ("O" - open)

**Mechanical connection:** Basic and connecting dimensions are given in dimensional drawings.

#### Electric connection

##### with terminal board (X):

- max. 24 terminals-connecting cable size max. 2,5 mm<sup>2</sup> – for EA ST 2
- max. 24 terminals - connecting cable size max. 1,5 mm<sup>2</sup> – for EA STR 2
- 3 cable bushings – 2 x M16 - cable diameter from 6 to 10,5 mm and 1 x M20 - cable diameter from 8 to 14,5 mm

- with connector (XC):**
- max. 32 terminals – connecting cable size max. 0,5 mm<sup>2</sup>
  - 2 cable bushings – 1 x M20x1,5 - cable diameter from 8 to 14,5 mm
  - 1 x M25x1,5 - cable diameter from 12,5 to 19 mm

- with protection terminal:**
- external and internal, mutually connected and marked with protection earthing mark.

Electric connection - according to **wiring diagrams**.

There must be power switch or motor circuit breaker included to the power supply which must be placed as close as possible to the device, easily accessible to the operator and marked as an disconnecting device of actuator.

### 3. Installation and dismantling of actuator

#### 3.1 Installation



**Abide by safety measures!**

Note:

Check again if placement of EA reply to chapter "Operation conditions". In case that operation conditions are different from recommended, consultation with producer is needed.

**Before starting of mounting the EA onto the valve:**

- Check again whether the EA was not damaged during storing.
- Check whether the adjusted operation stroke and connecting dimensions of the actuator (see the nameplate) are in compliance with the valve parameters.
- In case of inconsonance, perform adjusting according to the part "Adjustment".

#### 3.1.1 Mechanical connection

EA is by the producer adjusted to parameters according to the nameplate, with connecting dimensions according to the corresponding dimensional drawing and put it to a mid-position.

Before installation put the hand wheel on.

The actuators can be installed and operated in any position. In other than vertical position of EA, the pillars must be placed one above the other.

While installing leave enough space for dismantling of the upper cover to allow adjusting of the control parts.

#### Mechanical connection with connection dimensions according to DIN Standards

- Properly defat contact surfaces of the EA connecting flange and the valve.
- Set the actuator (A) to the mid-position and the valve (B) to the position "closed".
- Fasten EA to flange of valve (7) by screws (3) (with minimum mechanical raggedness of screws 8G) in the way you be able to move it.
- By turning of hand wheel approach the shaft of EA to valve's shaft.
- By turning of valve's shaft (4) connect valve's coupling of valve's shaft with the EA shaft (2). During of connecting pay attention to alignment both shafts.
- Check that the connecting flange of EA (1) fits in the valve.
- Tighten the screws with the cross system
- The valve output shaft (4) unscrew by one revolution and lock it with the nut (5) (to create pre-stressing against the valve seat).

**A ... electric actuator**

- 1 ... actuator flange
- 2 ... actuator output shaft
- 3 ... coupling screw

**B ... valve**

- 4 ... valve output shaft
- 5 ... locking nut
- 6 ... valve coupling
- 7 ... valve top body




Fig. 1

### Mechanical connection for pillar versions with flanges (fig.2)

- Set the actuator (A) to mid-position and the valve (B) to the position "closed".
- Loosen four screws (7) the coupling clamping parts (1) on the actuator shaft
- Place the actuator (A) onto the valve (4) and fix the actuator slightly with the screws, or with the central nut (5) (according to shape of connecting flange of EA) in the way you be able to move it.
- By turning hand wheel (1) move thread coupling EA toward shaft of the valve
- By turning of the coupling nut of EA connect the coupling of EA with shaft of the valve
- Tighten the screws, or central nut (5) with the cross system to fasten the actuator (2) and valve (4) flanges.
- Check the connection diameters in accordance with the Fig. 2.
- Unscrew the coupling nut (1) by one more revolution (to create the pre-stress against the valve seat), and tighten the coupling screws (7) firmly

#### Notes:

1. Minimum mechanical ruggedness of screws is 8G.
  2. If adjustment of the position-signalling unit or the transmitter in the production plant do not correspond with the EA connected this way, adjust the units.
- In the end of mechanical connection check correctness of the connection with the valve with rotating the hand wheel.




Fig.2

#### A ..... electric actuator

- 1 ..... coupling nut
- 2 ..... actuator flange
- 7 ..... coupling screw

#### B ..... valve

- 3 ..... valve shaft
- 4 ..... valve flange
- 5 ..... central nut
- 6 ..... lock nut

### Mechanical connection for pillar version - Fig. 3

#### Connection procedure:

- Check the label whether valve and actuator strokes are the same.
- Put the valve (B) to the position "closed" and the actuator (A) to a mid-position.
- Loosen the screws (2) located on the pillars (4).
- Screw alternatively the pillars (4) into the valve flange (8).
- Fasten the pillar nuts (2).
- Unscrew the coupling screws (3) to dismantle the coupling.
- By turning of hand wheel (5) approach the coupling of EA (1) to valve's shaft(6).
- Screw the coupling nut (1) onto the valve shaft (6) to reach the connection dimension H in accordance with the Table and the actuator label.
- Unscrew the coupling nut (1) by one revolution and lock it with a nut. (7).
- Tight the coupling screws(3). Secure the coupling nut towards shaft of valve by lock-nut(7).

#### A..... electric actuator

- 1 ..... coupling nut
- 2 ..... pillar nut
- 3 ..... coupling screw
- 4 ..... pillar
- 5 ..... hand wheel

#### B ..... valve

- 6 ..... valve shaft
- 7 ..... lock nut
- 8 ..... valve flange




Fig. 3

### 3.1.2 Electric connection and checking of function

Follow up with connecting the EA with mains or master system.



1. Follow instructions in the part "Requirements for professional qualification..!"
2. While laying electrical line abide by the instructions for heavy current installations.
3. Cables to terminal boards or connectors lead through bushings.
4. Before initiation EA into operation internal and external protection terminals are needed to be connected.
5. Feeding cables are to be fixed to the solid construction at most 150 mm from the bushings.
6. To prevent moisture from entering the actuator around the connecting cables, the cables must be sealed with silicone material at the point of penetration through device shell.

#### Connecting with the master system:

The EA can be controlled with:

- a built-in position controller
- an external position controller



1. If the EA is controlled with an external controller using unified signal from a two-wire transmitter (capacitive or resistive with a converter in two-wire connection), it is needed to arrange connecting of the two-wire transmitter loop to electrical earth of the successive external controller!
2. Connection can be performed only in one point, in any part of loop out of the EA.
3. Electronics of the two-wire transmitters is galvanically insulated that is why it can serve as an external source for supplying of several transmitters (their number depends on current which the source can supply).
4. Do not connect and disconnect live connectors !

#### Connecting to terminal board

- Check whether the type of current, supply voltage and frequency correspond with data on the nameplate of electric motor.
- Remove the upper cover.
- In case of the single-phase version the phase L1 and the lead N connect to the corresponding terminals. In case of the three-phase version connect the phase cables L1, L2 and L3 to U, V, W (terminals 2, 3, 4), the protection cables to the marked places of internal and external protection terminals.

*For operating of armature without stop ends is needed to connect the positional switches S3, S4 to the wiring power supply of electric motor before S1, S2. The switches S3, S4 are adjusted to the required stroke by producer.*

- Connect the control cables according to the wiring diagram placed into the internal side of the cover.
- Put the cover on and tighten it uniformly crosswisely.
- Tighten the cable bushings firmly to assure the protection enclosure rate.

#### Notes:

1. The EA are delivered with bushings, which in case of tight putting on the leads assure protection enclosure up to IP 68. For required protection enclosure it is needed to use rings according to the actual cable diameter.
2. While fixing the cable it is needed to count with allowed bend radius to avoid damaging or deformation of the sealing element of the bushing. The leads are to be fixed with the solid construction at most 150 mm from the bushings.
3. It is recommended to use screened cables to connect remote transmitters.
4. The face areas of the control part cover have to be before re-mounting clean, coated with a grease without any acid (e.g. vaseline) and sealing not damaged to avoid joint corrosion.
5. Reversation of the EA is sure, if the period between switching-off and switching-on of power supply for the reversed movement of the output part is minimally 50 ms.
6. Delay after switching-off, i.e. time since a reaction of switches till the motor is dead can be maximally 20 ms.
7. It is recommended to have the corresponding direction protection switched-off directly with the corresponding position or thrust switches.



**Abide by instructions of valve producers, whether switching-off in limit positions is to be realised with position or thrust switches!**



### After electric connection perform checking of function:

- Put the valve manually to a mid-position.
- Connect the EA electrically for the chosen direction of movement and watch the output part movement.
- If it does not correspond change the order of feeding phases (valid for 3x400V version), or change leads of the feeding phase to the corresponding terminals (valid for 230V version).
- Check the control unit switches connection with switching consequently the contacts of the corresponding switches with pressing the control elements at running of the EA (at proper connection) to the chosen direction. In case of proper connection the EA stops or indicates the adjusted position according to switching of the chosen switch. If any of the functions is fault check connecting of the switches according to wiring diagrams.

In the **STR 2 version** with the built-in **electronic controller** it is needed to perform **autocalibration** for assuring optimal functioning.

### The procedure is as follows

Put the EA to mid-position (the position and trust switches are not connect)

Press the button **SW1** for about 2 sec (i.e. till the **D3** diode is got on) to set the controller to the **autocalibration** mode. During this process the controller checks the feedback transmitter and the sense of turning, puts the EA to the positions open and closed, measures inertia mass in the directions "opening" and "closing", and loads the adjusted parameters into the EEPROM memory. In case that during the initialisation process an error occurs (e.g. in connection or adjustment) the initialisation process will be interrupted and the controller with the **D4** diode reports about the type of the error. Else after finishing the initialisation process the controller is put into the **regulation mode**. If needed to change adjusted parameters of the controller follow instructions given in the part Adjusting of actuator.

## 3.2 Dismantling



**Before dismantling it is required to disconnect the EA from mains!**  
**Do not connect and disconnect live connectors!**

- Disconnect the EA from mains.
- Disconnect the leads from the EA terminal boards and loosen the cables from bushings. Pull out the connectors in case of the connector version.
- Loosen the fixing screws of the EA flange and coupling screws and disconnect the EA from the valve.
- While sending the EA to be repaired put it into a package solid enough to avoid damages of the EA during transportation.

## 4. Adjusting of actuator



**Abide by safety measures!**

After mechanical connection, electrical connection and checking of connection and function start setting and adjustment of the device. The adjustment can be performed at a mechanically and electrically connected EA. This part describes adjustment of EA to specified parameters in case that any unit of EA is reset. Laying of adjusters of the control board is shown on Fig. 4 - applies to 230 V AC.




Fig. 4

#### 4.1 Gear unit adjustment

In the production plant switching-off thrust for both the "opening" direction (the thrust switch S1) as well as for the "closing" direction (the thrust switch S2) are adjusted to specified value  $\pm 10\%$ . If not agreed else they are adjusted to maximum value.

Adjustment and setting of the gear unit to other values without any testing device for thrust measuring is not possible.

#### 4.2 Adjustment of position-indicating unit (Fig. 5)

The EA are in the production plant adjusted to a fixed angle (according to the specification), given on the nameplate. While setting, adjusting and resetting follow these steps (Fig. 5):

- In the version with a transmitter put the transmitter out of mesh.
- Loosen the nuts (23) fixing cams still having the Belleville spring creating axial pressure.
- Put the EA to the position "open" and turn the cam (29) clockwise until the switch S3 (25) switches.
- Change setting of the EA by the angle, where the position "open" is to be indicated and turn the cam (31) clockwise until the switch S5 (27) switches.
- Put the EA to the position "closed" and turn the cam (28) counterclockwise until the switch S4 (24) switches.
- Turn the EA back by the angle, where the position "closed" is to be indicated and turn the cam (30) counterclockwise until the switch S6 (26) switches.
- Having the EA adjusted lock the cams with the central milled nut and counter-nut (23).

If not agreed else the signalling cams are set next to the limit positions. The signal possibility is available along the whole operation angle in both directions, i.e. 100%.




Fig. 5

#### 4.3 Adjustment of resistant transmitter (Fig. 6)

The **resistant transmitter** is in the EA **ST 2** used to function as a remote position indicator; in the EA **STR 2 with controller** to function as a feedback in the position controller and if needed also in the position of a remote resistant position indicator. Before the resistant transmitter adjustment the position switches have to be adjusted. Adjustment consists in setting of the resistance in the defined limit position of the EA.

##### Notes:

*In case that the EA is not used in the whole stroke range given on the nameplate, the resistance in the limit position "open" is proportionally reduced.*

*In the EA **STR 2 with controller** 2000W resistant transmitters are used. In the other cases if the resistant branch is lead to the terminal board the resistance of the transmitters is according to the customer's specification.*

To adjust the transmitter follow these steps:

- Loosen the fixing screws (9) of the transmitter holder and push the transmitter out of mesh.
- Connect a meter for resistance measuring to the terminals 71 and 73 of the EA **ST 2** terminal board, or to the terminals 6 and 7 of the EA **STR 2 with controller** terminal board.
- Put the actuator to the position "closed" (with the hand wheel, or with the local electric position control until the corresponding position switch S2 or S4 switches).
- Rotate the transmitter shaft until resistance of  $\leq 5\%$  of the nominal transmitter resistance can be read on the meter in case of EA **ST 2**, or 3 up to 7% of the nominal transmitter resistance in case of EA **STR 2**, or in case of EA **ST 2** with EPV, i.e. with the resistant transmitter with the converter PTK1
- In the position put the transmitter to mesh with the drive wheel and fix the fixing screws on the transmitter holder.
- Disconnect the meter from the terminal board.




Fig. 6

#### 4.4 Adjustment of the Electronic Position Transmitter (EPV) - the Resistive Transmitter (Potentiometer) with the Converter PTK 1

##### 4.4.1 EPV – the 2-wire version (Fig. 7,7a)

The position transmitter with the converter PTK1 is in the plant adjusted to have the output current signal on the terminals 81-82 (the wiring diagram Z10a for EA ST, or Z241a for EA STR) as follows:

- in the position „open“ .. 20 mA
- in the position „closed“ ..... 4 mA

If the transmitter requires a new adjustment follow these steps:

##### **Adjustment of the EPV in EA ST:**

- Put the actuator to the position „closed“ and switch the power supply off.
- Adjust the resistive transmitter according to the previous chapter. The resistance is to be metered on the terminals X-Y (Fig. 7,7a). The used transmitter resistance is 100  $\Omega$ .
- Switch the converter's power supply on.
- Turn the adjusting trimmer ZERO to adjust the output current signal rate measured on the terminals 81-82 to 4mA.
- Set the actuator to the position „open“.
- Turn the adjusting trimmer GAIN to adjust the output current signal rate measured on the terminals 81-82 to 20mA.
- Check the output signal of the converter in the both limit positions, and repeat the procedure if needed.

##### Note:

The output signal of 4-20mA can be adjusted at the range from 75 up to 100% of the rated stroke stated on the actuators nameplate. At values less than 75% the value 20mA is reduced proportionally.

##### **Adjustment of the EPV in EA with controller**

- Disconnect the circuit with removing a jumper on the terminals 81 and 82.
- Disconnect the control signal from the terminals 86/87 and 88.
- Set the actuator to the direction "OPENING" or "CLOSING" with the hand wheel, or with connecting power to the terminals 1 and 20 for the direction "OPENING" or 1 and 24 for the direction "CLOSING".
- Set the actuator to the position "CLOSING" and switch the converter off on the terminals 1 a 61.
- Adjust the resistive transmitter according to the previous chapter. The resistance is to be metered on the terminals X-Y (Fig. 7,7a).
- Connect power supply to the terminals 1 and 61.
- Turn the adjusting trimmer ZERO to adjust the output current signal rate measured on the terminals 81-82 to 4mA.
- Set the actuator to the position „open“.
- Turn the adjusting trimmer GAIN to adjust the output current signal rate measured on the terminals 81-82 to 20mA.
- Check the output signal of the converter in the both limit positions, and repeat the procedure if needed.
- Having the transmitter adjusted put the jumper again on the terminals 81 and 82 in case that the output signal wont be used (the circuit through the terminals 81 and 82 should be closed).
- Connect the control signal to the terminals 86/87 and 88.




Fig.7




Fig.7a

#### 4.4.2 EPV – 3-wire version (Fig. 8,8a)

The resistive transmitter with the converter is in the plant adjusted to have the output current signal metered on the terminals 81-82 (the wiring diagram Z257a - without any power supply, or Z260a - with a power supply) as follows:

- in the position „open“ ..... 20 mA resp. 5 mA, resp. 10 V
- in the position „closed“ ..... 0 mA resp. 4 mA, resp. 0 V

according to the specified version of the converter.

If the transmitter requires a new adjustment follow these steps:

- Put the actuator to the position "closed" and switch the power supply off.
- Adjust the resistive transmitter according to the previous chapter. The resistance is to be metered on the terminals X-Y (Fig. 8,8a). The used transmitter resistance is 2000Ω or 100 Ω.
- Switch the converter's power supply on.
- Turn the adjusting trimmer ZERO to adjust the output current signal rate measured on the terminals 81-82 to 0 mA or 4mA.
- Set the actuator to the position „open“.
- Turn the adjusting trimmer GAIN to adjust the output current signal rate measured on the terminals 81-82 to 20mA or 5 mA..
- Check the output signal of the converter in the both limit positions, and repeat the procedure if needed.

Note:

The output signal of (0-20mA, 4-20mA or 0-5mA - according to the specification) can be adjusted at the range from 85 up to 100% of the rated stroke stated on the actuator's nameplate. At values less than 85% the value of the output signal is reduced proportionally.




Fig. 8





Fig.8a

#### 4.5 Adjustment of the Capacitive Transmitter CPT1/A (Fig.9)

The chapter describes adjustment of the capacitive transmitter to the specified parameters (standard values of output signals) in case they are reset. The capacitive transmitter serves as a position transmitter of electric actuators with unified output signal of 4÷20 mA in electric actuators **ST**, or as a feedback of a position controller, or if required it functions also as a remote position transmitter of electric actuators with unified output signal of 4÷20 mA in electric actuators **STR with controllers**.

Note:

*In case that reversed output signals are needed (in the position "OPEN" minimum output signal) contact personnel of service centres.*

The capacitive transmitter CPT1/A is adjusted by the producer to the fixed operation stroke according to the order and wired according to the wiring diagrams placed into the cover. Check the power supply of the user after connecting to terminal of the terminal board before the transmitter is electrically checked. Adjustment of the capacitive transmitter can be performed when the position switches are adjusted. The adjustment is performed with the power supply of 230 V/50 Hz and ambient temperature of  $20 \pm 5^\circ\text{C}$ .

The following versions of electric actuators with built capacitive transmitters can be specified :

- A) The version without any power supply** (2-wire version) for EA **ST**
- B) The version with a power supply** (2-wire version) for EA **ST**
- C) The version CPT as a feedback to the position controller** for EA **STR with controllers**

##### A.) Adjustment of the Capacitive Transmitter without any Power Supply

Before connecting check the power supply. The measured voltage should be in range from 18 up to 28 V DC.



*The voltage of the power supply must not be in any case higher than 30 V DC. The transmitter can be irreversibly damaged*

While checking or adjusting the output signal of 4÷20 mA follow these steps:

- Connect a mA meter of precision class 0,5 and loading resistance lower than  $500\Omega$  serially with the transmitter (pole „-“; terminal 82)
- Put the actuator to the position "CLOSED", the signal value should decrease.
- Check the signal value for the position "CLOSED" (4 mA).
- Tune the signal with loosening the fixing screws (15) and turning the trimmer (10) until the required value of 4 mA is reached. Tighten the fixing screws.
- Put the actuator to the position "OPEN", the signal value should raise.
- Check the signal value for the position "OPEN" (20 mA).
- Tune the signal with turning the trimmer (20) until the required value of 20 mA is reached.
- Check the signal value for the position "CLOSED" and then for the position "OPEN".
- Repeat the procedure until the change from 4 to 20 mA is reached with deviation less then 0,5 %.
- Disconnect the meter and lock the screws with a varnish.




Fig. 9

##### B.) Adjustment of the Capacitive Transmitter with the Power Supply:

- 1.) Check the power supply: 230 V AC  $\pm 10\%$  on the terminals 1, 61
- 2.) While checking or adjusting the output signal of 4÷20 mA follow these steps:
  - Connect a mA meter of precision class 0,5 and loading resistance lower than  $500\Omega$  on the terminals 81, 82.
  - Follow the procedure described in the previous chapter A.

##### C.) Adjustment of the Capacitive Transmitter Served as a Feedback of the Position Controller

While checking or adjusting the output signal of 4÷20 mA follow these steps:

- Disconnect the circuit on the terminals 81 and 82 removing the jumper.
- Connect power supply to the terminals 1 and 61.
- Disconnect the control signal from the terminals 86 and 88.
- Put the actuator to the direction "OPENING" or "CLOSING" with the hand wheel or connecting power supply to the terminals 1 and 20 for the direction "OPENING", or 1 and 24 for the direction "CLOSING".

- Connect a mA meter of precision class 0,5 (e.g. digital) and loading resistance lower than 500Ω on the terminals 81,82.
- Follow the procedure for the version without any power supply described in the previous chapter A.
- Having the transmitter adjusted put the jumper again on the terminals 81 and 82 in case that the output signal wont be used (the circuit through the terminals 81 and 82 should be closed).
- Connect the control signal to the terminals 86/87 and 88



*The user has to arrange grounding of the 2-wire circuit of the capacitive transmitter to the electrical ground of a joined controller, computer, etc. The grounding should be performed only in one place in any part of the circuit outside the electric actuator!*

**Note:**

*The trimmer (20) can be used to adjust the output signal of the capacitive transmitter to any value of operation stroke in range from ca 40% up to 100% of the value of the operation stroke adjusted by the producer and stated on the actuator's nameplate.*

## 4.6 Adjustment of position controller

The built-in position controller REGADA of new generation is a user-friendly control system to control actuators with an analogue signal. The controller takes advantages of high-power RISC processor MICROCHIP to perform all functions. It provides also continuous automotive diagnostics of the system, error messages as well as number of relay switching and number of controller's operation hours. Placing an analogue signal onto the input terminals of the terminal board 86 (GND, -) and 88 (+) causes that the EA output is reset.

Required parameters and functions can be programmed using function buttons SW1 - SW2 and LED diodes D3 - D4 placed directly on the controller, see Table 2.

### 4.6.1 Setting of controller

The controller's microprocessor unit is in the production plant programmed to parameters given in **Table 2** (Note 2).

Setting of the controller is performed using buttons and LED diodes. Adjust the position and thrust switches and the position transmitter before adjustment of the controller.

Laying of adjusters and signalling elements on the board of the REGADA controller is shown on Fig.10:




Fig. 10

<b>SW1 button</b>	starts an initialisation routine and allows listing in the adjust menus
<b>SW2 button</b>	setting of parameters in the chosen menu
<b>D1 diode</b>	power on indication
<b>D2 diode</b>	motion to the direction "opening" indication (green) - "closing" (red) indication
<b>D3 diode</b>	(yellow light) number of blinking codes indicates chosen adjust menu
<b>D4 diode</b>	(red light) number of blinking codes indicates adjusted parameter of the controller from the chosen menu

**Table 2**

D3 (yellow) diode number of blinking	Adjust menu	D4 (red) diode number of blinking	Adjusted parameter
1 blink	control signal	1 blink	0-20mA
		2 blinks	<b>4-20 mA (*) (**)</b>
		3 blinks	0-10V DC
2 blinks	response for signal SYS-TEST	1 blink	EA opens receiving signal SYS
		2 blinks	EA closes receiving signal SYS
		3 blinks	<b>EA stops receiving signal SYS (*)</b>
3 blinks	mirroring (ascending/descending characteristics)	1 blink	EA CLOSING at increasing of control signal
		2 blinks	<b>EA OPENING at increasing of control signal (*)</b>



4 blinks	insensitiveness of controller	1 to 10 blinks	insensitiveness of controller of 1-10% (3% set by the producer) (*)
5 blinks	way of regulation	1 blink	narrow thrust
		2 blinks	<b>narrow position (*)</b>
		3 blinks	wide thrust
		4 blinks	wide position

Notes:

1. The controller at autocalibration automatically sets the feedback type - resistant/current

2. (\*) Parameters set in the production plant, if customer has not stated else.

3. (\*\*) Input signal  
4 mA - position "closed"  
20 mA - position "open"

**Standard setting of controller (programmed RESET of controller)** - in case of any problems with setting of the parameters it is possible with pressing both **SW1** and **SW2** at the same time and then switching power on to set the standard parameters.

#### Controller setting procedure:

- Set the actuator into a mid-position.

The initialisation routine starts at the switched-on controller, zero system deviation and short pressing of the SW1 button for ca 2 sec (i.e. until the diode D3 got on). Loosing the button some of the default menus starts (usually control signal) what is shown with 1 blink on the D3 diode as well as one of the default parameters (usually control signal of 4-20mA) what is shown with 1 blink on the D4 diode. Then the required parameters of the controller can be changed according to Table 2:

- press shortly the SW1 button to list the menu shown with the blinking number on the D4 diode.
- press shortly the SW2 button to set parameters shown with the blinking number on the D4 diode.

After changing the parameters according to the user's requirements, switch the controller to autocalibration using the SW1 button pressed for approx. 2 sec (i.e. until the diode D3 lights up), which is signaled by flashing the yellow LED D3 6 times. During this process, the controller checks the feedback transmitter and the direction of rotation, moves the ES to the open and closed positions, measures the inertial masses in the "OPEN" and "closes" directions and saves the set parameters in the EEPROM memory. In case that during the initialisation process an error occurs (e.g. in connection or adjustment) the initialisation process will be interrupted and the controller with the D4 diode reports about the type of the error. Else after finishing the initialisation process the controller is put into the regulation mode.

#### Error messages of the controller with D4 diode at initialisation:

- 4 blinks ..... improper connection of the thrust switches
- 5 blinks ..... improper connection of the feedback transmitter
- 8 blinks ..... bad sense of actuator's turning direction or adverse connection of the feedback transmitter

### 4.6.2 Watching operation and error states

Watching operation and error states is possible with the EA open.

#### a.) Operation status with the D3 LED diode indicating:

- it is continuously lighting - the controller regulates
- it is continuously not lighting - system deviation in the insensitiveness range - the EA has stopped

#### b.) Error state with the D4 and D3 LED diodes indicating - D4 continuously lighting, D3 indicates error state with blinking

1 blink (repeated):	- indication of the "TEST" mode - the EA is put to the position according to the signal in the "TEST" menu (at connecting the 66 and 86/87 terminals)
2 blinks (repeating after short pause):	- missing of control signal - the EA is put to the position according to the signal in the "TEST" menu
4 blinks (repeating after short pause):	- thrust switches activity indication (the EA switched-off with the thrust switches in a mid-position)
5 blinks (repeating after short pause):	- failure of the feedback transmitter - the EA is put to the position according to the signal in the "TEST" menu
7 blinks (repeating after short pause):	- control signal (current at range 4-20mA less than 4mA (3.5mA))

## 5. Service, maintenance and troubleshooting

### 5.1 Service



1. In general it is provided that service of the EA is performed by a qualified worker in accordance with requirement given in Chapter 1!
2. After putting the EA into operation it is needed to verify whether during manipulation any scratch on surface occurred, it is to be removed to prevent actuator against corrosion!

The EA ST or STR requires just negligible service. Proper putting into operation is a recondition of reliable operation.

The service of the EA leads from the operation conditions and usually resides in information processing for further arranging of required functions.

The stuff has to perform prescribed maintenance to prevent the EA during operation against impacts of environment, which exceed the frame of allowed influences.

#### Electric local control: - additional equipment (Fig.11)

In case of need (during adjusting, function checking etc.), but power supply must be provided, is possible to readjust actuator by electric local control. After switching the mode switch to the mode "LOCAL" it is possible by the direction switch to control motion of the output part to setting direction. Signal lights indicate achievement of limit position at relevant direction

The control is possible after removing the padlock (1). Control mode selection is changed by sequential pressing of the button (2) **REMOTE-OFF-LOCAL** to "Remote" "Shut off", "Local", "Shut off". Individual modes are cycled by sequential pressing. The selection is indicated by LEDs visible on the front panel of the local control.

The presence of the supply voltage for the control of the local control is signalled by the lighting of one of the three LEDs REMOTE (6), OFF (7), or LOCAL (8).

#### Individual local control modes:

"OFF" mode - in this mode, the EA cannot be controlled remotely or locally. The mode is signalled by the lighting of the OFF LED (7).

The „**LOCAL**“ mode - this mode enables EA control in the open and close direction and to stop using buttons **OPEN** (3) (open), **CLOSE** (4) (close) and **STOP** (5). The „**LOCAL**“ mode is indicated by **LOCAL** (8) LED being lit. When **OPEN** button is pressed in this mode, it is indicated by **OPEN** LED being lit (9). When **CLOSE** button is pressed in this mode, it is indicated by **CLOSE** LED being lit (10). When **STOP** button is pushed, the signal LEDs **OPEN** (9) and **CLOSE** (10) are switched off.

The „**REMOTE**“ mode - in this mode the EA can be remotely controlled by commands from master system. The „**REMOTE**“ mode is indicated by **REMOTE** (7) LED being lit. In this mode the OPEN, STOP and CLOSE buttons are not functional.

After finishing the work with electrical local control, we recommend to return the padlock to button (2) in mode „**REMOTE**“ and lock out the device to avoid unwanted tampering by unauthorized person. Padlock can be fitted and locked to button (2) in any local control mode.






Fig. 11

## 5.2 Maintenance - extent and periodicity

During inspections and maintenance is needed to tighten all screws and nuts that affect the tightness and coverage. Similarly, once a year should be checked and if necessary tighten mounting screws of the terminal wires and assuring of the slip-on joints with wires.

The interval between two preventive inspections is four years.

The replacement of cover gaskets and gasket of an oil filling is needed in case of damage or after 6 years of the operation.

The grease in the supplied actuators is designed for the lifetime of the product.

It is not necessary to change the grease during the operation of the actuator.

### Lubrication:

- gear part - in versions for climate with temperatures  $-25^{\circ}\text{C}$  till  $+55^{\circ}\text{C}$  – grease HF 401/0 (GLEIT- $\mu$ ) resp. GLEITMO 585 K
- in versions for climate with temperatures  $-50^{\circ}\text{C}$  till  $+40^{\circ}\text{C}$  grease ISOFLEX TOPAS AK 50
- in versions for climate with temperatures  $-60^{\circ}\text{C}$  till  $+40^{\circ}\text{C}$  grease DISCOR R-EP 000.
- linear adapter – grease GLEIT-  $\mu$  - HP 520M (to  $-25^{\circ}\text{C}$ ) resp. HP 520S (to  $-40^{\circ}\text{C}$ ).



**Lubrication of the valve stem is independent on maintenance of the EA!**

After every potential flooding of the product check, whether there is no water inside. After eventual water penetration, dry the product before repeated putting into operation and replace damaged sealings, resp. other parts of EA. identically check also tightness of cable bushings and replace them, if they are damaged.

- Every six months it is recommended to perform one check move in frame of adjusted operation stroke to verify reliability of functioning with setting back to the original position.
- If the audit rules do not determine else the inspection of EA is performed ones a year and tightening of all connecting and grounded screws have to be checked to avoid overheating.
- After 6 months from putting of EA into operation and once a year it is recommended to check tightening of fixing screws between the EA and the valve. (Tighten the screws with the cross system.)



- While connecting and disconnecting of the EA check the tightness of cable glands – those with damaged sealings should be replaced by new ones of the approved type!
- Keep the EA clean and take care about removing impurities and dust. The cleaning has to be performed regularly according to the operation possibilities and requirements.

### 5.3 Troubleshooting

At failure of power supply the EA stops in the position where it was before the failure. If needed the EA can be set only with the manual control (the hand wheel). After restoration of power the EA is prepared for operation.

In case of failure of any element of the EA it can be changed by a new one. Entrust the change to a service centre.

In case of an EA failure, which cannot be eliminated directly in operation, follow instructions for under-guaranty and after-guaranty service.

For controller repair a F1,6 A subminiature fuse for PCB should be used, alternatively also F 2A, 250 V e.g. Siba type 164 050.1,6 or MSF 250, and for DB .... voltage source repair a M160 mA, 250V fuse, e.g. Siba, or MSF 250.

Note: If the EA requires dismantling follow the chapter "Dismantling".



***Taking the EA to pieces for repair purposes is allowed only by professionally qualified persons trained in the production plant or by a contracted service centre!***

## 6. Accessories and spare parts

### 6.1 Accesories

The EA is delivered with the hand wheel.

### 6.2 Spare parts list


Spare part	Order Nr.	Position	Figure
Electric motor; 20W/70 VA; 230V AC	63 592 118	7	4
Electric motor; 60W/120 VA; 230V AC	63 592 322	7	4
Electric motor; 90W/150 VA; 3x400V AC	63 592 328	7	4
Elektromotor 93 W; 24 V AC/DC	63 592 294	7	4
Resistant wire transmitter (potentiometer) 1x100Ω	64 051 812	5	6, 4
Resistant wire transmitter (potentiometer) 2x100Ω	64 051 814	5	6, 4
Resistant wire transmitter (potentiometer) 1x2000Ω	64 051 827	5	6, 4
Resistant wire transmitter (potentiometer) 2x2000Ω	64 051 825	5	6, 4
Capacitive transmitter	64 051 499	10	9
Sealing	62 732 119	1	4
Cable gland M16	63 456 595	12	4
Cable gland M20	63 456 596	12	4
Terminal board EKL	63 456 601	6	4

**Warning:** By supplying spare parts, the manufacturer is not responsible for damages caused by their disassembly and assembly. Installation, replacement of spare parts must be performed by authorized, qualified personnel.





## 7. Enclosures




### 7.1 Wiring diagrams

#### Wiring diagrams










## Wiring diagrams EA ST 2 – Electric connection to terminal board






## Wiring diagrams EA ST 2 – Electric connection to connector















## Wiring diagrams STR 2 with controller



## Wiring diagrams EA STR 2 – Electric connection to terminal board




## Wiring diagrams EA STR 2 – Electric connection to connector



**Diagram of work of position and thrust switches Microswitches: S1, S2, S3, S4, S5, S6:**

	outlets	open close	
S1	NC - COM		
	COM - NO		
S2	NC - COM		
	COM - NO		
S3	NC - COM		
	COM - NO		
S4	NC - COM		
	COM - NO		
S5	NC - COM		
	COM - NO		
S6	NC - COM		
	COM - NO		



Operating stroke

Connected contact

**Legend:**


- Z1a ..... connection of single-phase electric motor  
 Z5a ..... connection of single resistive transmitter  
 Z6a ..... connection of double resistive transmitter  
 Z10,Z10a,Z10b .. connection of resistive transmitter with current converter or capacitive transmitter - 2-wire without power supply  
 Z11a, Z1a/Z11a . connection of position switches for single-phase electric motor  
 Z12a,Z12e ..... connection of position switches for 3-phase electric motor  
 Z21a ..... connection of additional position switches for EA STR 2  
 Z41a ..... connection of space heater and thermal switch for EA STR 2  
 Z78a ..... connection of 3-phase electric motor  
 Z632c,ZK632c ... connection of 3-phase electric motor with local control  
 Z632b,ZK632b ... connection of 3-phase electric motor with reverse contractors and local control  
 Z633,ZK633 ..... connection of 1-phase electric motor with local control  
 Z288a ..... connection of additional position switches for EA STR 2 with voltage 3x400 V AC  
 Z240a ..... connection of EA STR 2 with controller and with resistive feedback with 1~motor  
 Z241a ..... connection of EA STR 2 with controller and with current feedback with 1~motor  
 Z250a ..... connection of EA STR 2 with controller and with current feedback with 3~motor  
 Z251a ..... connection of EA STR 2 with controller and with resistive feedback with 3~motor  
 Z257a ..... connection of transmitter – 3 –wire without power supply  
 Z260a ..... connection of transmitter with current converter – 3 –wire with power supply  
 Z269a ..... connection of transmitter with current converter or capacitive transmitter -2-wire with power supply  
 Z269f, Z378b ..... connection of transmitter with current converter or capacitive transmitter -2-wire with power supply – 24 V DC  
 Z303 ..... connection of 3-phase electric motor with reverse contractors  
 Z378 ..... connection of resistive with current converter or capacitive transmitter 2 - wire with supply – 24 V AC/DC  
 Z626a,ZK626a ... connection of EA ST 2 with electric motor 24 V DC  
 Z634a,ZK634a ... connection of EA ST 2 with electric motor 24 V DC and with local control  
 Z626b,ZK626b ... connection of EA ST 2 with electric motor 24 V AC  
 Z634b,ZK634b ... connection of EA ST 2 with electric motor 24 V AC and with local control  
 Z638, ZK638 ..... connection of EA STR 2 with controller and resistant feedback for electric motor 24 V DC  
 Z639, ZK639 ..... connection of EA STR 2 with controller and current feedback for electric motor 24 V DC  
 Z640, ZK640 ..... connection of EA STR 2 with controller and resistant feedback for electric motor 24 V AC  
 Z641, ZK641 ..... connection of EA STR 2 with controller and current feedback for electric motor 24 V AC  
 Z251c ..... connection EA STR 2 with 3 phase electric motor, with positioner with resistive feedback and with contactors with errors relay


B1 .....	single resistant transmitter	KM1, KM2 .....	reverse contactor
B2.....	double resistant transmitter	F2 .....	space heater thermal switch
B3.....	capacitive transmitter, or el. position transmitter	X.....	terminal board
S1.....	torque switch "open"	XC .....	connector
S2.....	torque switch "closed"	N.....	position controller
S3.....	position switch "open"	I/U.....	input (output) current (voltage) signals
S4.....	position switch "closed"	H1.....	indication of "open" limit position
S5.....	additional position switch "open"	H2.....	indication of "closed" limit position
S6.....	additional position switch "closed"	H3.....	indication of "electric local control"
M.....	electric motor	SA1 .....	rotary switch with key
C .....	capacitor		"remote-0-electric local" control
Y.....	brake of electric motor	SA2 .....	rotary switch "open-stop-closing"
E1.....	space heater	R.....	resistor (for the version of 230 V AC)
F1.....	electric motor thermal protection	R <sub>L</sub> .....	voltage-dropping resistor (for 230V only)

#### Notes:

1. In case, that output signal from capacitive transmitter (wiring diagram Z241a, Z250a) is unused (incomplete circuit between terminal 81 and 82), it is required to connect terminals 81 and 82 by jumper (jumper is connected at manufacturing plant for connecting to terminal board only). By using output current signal from capacitive transmitter it is needed to remove jumper.
2. For the EA version with feeding voltage 24 V AC is not needed to connect ground wire PE.
3. In the version equipped with the controller device while using the feedback from transducer CPT; when using the output signal there has been no galvanic isolation of the signal from the input one!
4. In case that galvanically separated output signal is needed it is necessary to use galvanical separation element (is not part of delivery), e.g. NMLSG.U07/B (producer SAMO Automation s.r.o.). After discussion this module could be supplied by EA producer.


7.2 Dimensional drawings





B	112	609/629	80/100	$\phi 80$	2	$\phi 105$	$\phi 13$	M20x1.5
A	110	609/629	80/100	$\phi 65H12$	3	-	-	M16x1.5
VERSION	H	L/L*	W/W*	D1	L1	D2	D3	M14x2


P-1246a/A,B



D	126	622/642	M20	25	MAX.80/MAX.100	M20x1.5 M16x1.5
C	74	570/590	M20	25	MAX.80/MAX.100	
B	30	526/546	M20	25	MAX.80/MAX.100	
A	92	588/608	M16	40	MAX.80/MAX.100	
VERSION	H	L/L*	S	V	W/W*	Z


P-1247a/A-D






P-2000/B	112	609/629	80/100	ø80	ø105	ø13	M20x1.5
P-2000/A	110	609/629	80/100	ø65H12	—	—	M16x1.5
VERSION	H	L/L*	W/W*	D1	D2	D3	Z

P-2000a



P-2001/D	126	622/642	MAX.80/MAX.100	M20	M20x1.5 M16x1.5
P-2001/C	74	570/590	MAX.80/MAX.100	M20	
P-2001/B	30	526/546	MAX.80/MAX.100	M20	
P-2001/A	92	588/608	MAX.80/MAX.100	M16	
VERSION	H	L/L*	W/W*	D3	Z

P-2001a



C	125	621/-	80/-	ø68	-	-	-	7/8"- UN9
VERSION	H	L/L*	W/W*	D1	L1	D2	D3	Z

P-1246a/C

**7.3 Guarantee service check report**

<b>Service center:</b> D	
<b>Date of repair:</b>	<b>Guarantee repair no.:</b>
<b>User of actuator:</b>	<b>Claim applied by:</b>
<b>Actuator type number:</b>	<b>Actuator production number:</b>
<b>Product claim fault:</b>	<b>Detected product fault:</b>
<b>Used spare parts:</b>	
<b>Remarks:</b>	
<b>Issued on a day:</b>	<b>Signature:</b>

**7.4 Post guarantee service check report**

<b>Service center:</b>	
<b>Date of repair:</b>	
<b>User of actuator:</b>	<b>Actuator operating place :</b>
<b>Actuator type number:</b>	<b>Actuator production number:</b>
<b>Detected product fault:</b>	
<b>Used spare parts:</b>	
<b>Remarks:</b>	
<b>Issued on a day:</b>	<b>Signature:</b>

### **7.5 Commercial representation**

#### **Slovak Republic:**

**Regada, s.r.o.,**  
Strojnícka 7,  
080 01 Prešov  
Tel.: +421 (0)51 7480 460,  
Fax: +421 (0)51 7732 096,  
E-mail: [regada@regada.sk](mailto:regada@regada.sk)